


SMART WEIGHING SOLUTIONS



rinstrum

X320 IP69K
Digital Indicator
Reference Manual

003X-610-100-M01

Copyright

All Rights Reserved. No part of this document may be copied, reproduced, republished, uploaded, posted, transmitted, distributed, stored in or introduced into a retrieval system in any form, or by any means (electronic, mechanical, photocopying, recording or otherwise) whatsoever without prior written permission of Rinstrum Pty Ltd.

Disclaimer

Rinstrum Pty Ltd reserves the right to make changes to the products contained in this manual in order to improve design, performance or reliability.

The information in this manual is believed to be accurate in all respects at the time of publication, but is subject to change without notice. Rinstrum Pty Ltd assumes no responsibility for any errors or omissions and disclaims responsibility for any consequences resulting from the use of the information provided herein.

SPECIAL NOTE

Trade Use of the Instrument

This manual may occasionally make reference to Trade Use settings of the instrument.

Some individual settings may not be legal for trade use. Please check regulations with the appropriate Weights and Measures Authority.

Table of Contents

1.	INTRODUCTION	4
1.1.	Overview	4
1.2.	Approvals	5
1.2.1.	Trade versions	5
1.3.	The Manuals Set	5
1.4.	Document Conventions	5
2.	SPECIFICATIONS	6
3.	INSTALLATION	7
3.1.	Introduction	7
3.2.	General Warnings	7
3.3.	Electrical Safety	7
3.4.	Cleaning	7
3.5.	Cable Connections	8
3.6.	DC Power (DC PWR + , DC PWR –)	8
3.7.	Load Cell Connection	8
3.7.1.	Load Cell Signals and Scale Build	8
3.7.2.	4-Wire Connection	9
3.7.3.	6-Wire Connection	9
3.8.	Auxiliary Connections	10
3.8.1.	RS-232 Serial	10
3.8.2.	Remote Input	13
3.8.3.	Outputs	14
3.9.	opto-LINK (Optional)	15
3.10.	Connecting Shields	17
3.10.1.	Cable Shield Connection and Earthing	17
3.11.	Regulatory Sealing Requirements	17
4.	DATA ENTRY	18
4.1.	Editing Annunciators	18
4.2.	Numeric Entry	19
4.3.	Selections and Options	19
5.	BASIC OPERATION	20
5.1.	Display and Controls	20
5.1.1.	Front Panel: Visual Display	20
5.2.	Operation Keys	21
5.2.1.	Primary Function	21
5.2.2.	Editing Function	22
5.3.	Stability Considerations	22
5.4.	POWER Key	22
5.4.1.	Automatic Operation	22
5.5.	ZERO Key	23
5.6.	TARE Key	23
5.6.1.	Preset Tare	23
5.7.	GROSS/NET Key	24
5.8.	opto-LINK Activation	24
5.9.	PRINT Key	24
5.10.	FUNCTION Key	24
6.	CONFIGURATION	25
6.1.	General Setup Information	25
6.2.	Basic Weighing Terminology	25
6.3.	Dual Range Operation (K306 only)	26
6.4.	Gravity Compensation (K306 Only)	27
6.5.	Accumulation Mode (K307 Only)	27
6.6.	Filtering Techniques	28
6.7.	Industrial vs NSC, OIML and NTEP Modes	28
6.8.	Calibration Counter	28
6.9.	Passcodes	29
6.9.1.	Full Setup Passcode	29
6.9.2.	Safe Setup Passcode	29

6.9.3.	Setup Lock-Out.....	29
7.	ACCESSING SETUP	30
7.1.	Accessing Setup	30
7.1.1.	Full Setup.....	30
7.1.2.	Safe Setup	30
7.1.3.	Setup Display Prompts	31
7.2.	Exiting Full or Safe Setup.....	31
8.	SETUP MENUS	32
8.1.	Groups and Items.....	32
8.1.1.	GRP (Group).....	32
8.1.2.	ITM (Item)	32
8.2.	Setup Menus	33
8.2.1.	BUILD (Scale Build)	33
8.2.2.	OPTION (Scale Options)	34
8.2.3.	CAL (Scale Calibration)	35
8.2.4.	SPEC (Special Settings Menu)	36
8.2.5.	SERIAL (Serial Communications Options)	39
8.2.6.	CHECK.W (Check Weighing Settings)	40
8.2.7.	CLOCK (Clock Settings)	40
8.2.8.	TEST (Special Test Functions)	40
8.2.9.	FACTRY (Factory Adjustment Menu)	41
8.2.10.	– End – (Leaving Setup)	41
9.	CALIBRATION	42
9.1.	Performing a Digital Calibration with Test Weights	42
9.1.1.	ZERO (Zero Calibration Routine).....	43
9.1.2.	SPAN (Span Calibration Routine).....	43
9.2.	Performing a Calibration with Direct mV/V Entry	43
9.2.1.	DIR.ZER (Direct Zero Calibration Entry).....	43
9.2.2.	DIR.SPN (Direct Span Calibration Entry).....	44
9.3.	Using Linearisation (K304 only)	44
9.3.1.	ED.LIN (Edit Linearisation Points) (K304 only)	45
9.3.2.	CLR.LIN (Clear Linearisation) (K304 only)	45
9.4.	Using Gravity Compensation (K306 only)	46
10.	SERIAL OUTPUTS	47
10.1.	Network Communications	47
10.1.1.	COMM Protocol	47
10.1.2.	Ring Network Enhancement	47
10.2.	Automatic and Single Output	47
	Master Serial Output.....	48
10.3.	Printing	48
10.3.1.	Standard Printing	49
10.3.2.	Programmable Printing	50
11.	CHECK WEIGHING	52
11.1.	Output Connection	52
11.2.	Check Weighing Operation	52
12.	SPECIAL FUNCTIONS	53
12.1.	Introduction	53
12.2.	Key Functions	53
12.2.1.	NONE.....	53
12.2.2.	TEST.....	53
12.2.3.	COUNT	53
12.2.4.	UNITS	53
12.2.5.	HOLD and PEAK HOLD	54
12.2.6.	LIVE.WT.....	54
12.2.7.	SHOW.T.....	55
12.2.8.	HI.RES.....	55
12.2.9.	A.TARE.....	55
12.2.10.	CHECK.W	56
13.	APPENDIX	57
13.1.	Dimensions	57

13.2.	Sealing Details	58
13.3.	Setup Menu Quick Reference	59
13.4.	Error Messages.....	61
13.4.1.	Weighing Errors	61
13.4.2.	Setup and Calibration Errors.....	62
13.5.	Diagnostic Errors.....	63
13.6.	Glossary Terms.....	64
13.7.	List of Figures.....	64
13.8.	List of Tables.....	64
14.	INDEX.....	65

1. Introduction

This instrument is an IP69K rated precision digital indicator using the latest Sigma-Delta analogue to digital conversion technology to ensure fast and accurate weight readings.



Figure 1: Weight Indicator

The setup and calibration of the instrument are digital, with a non-volatile security store for all setup parameters.

The instrument may be operated from 9.6V, 12V or 24V batteries or a DC power source from 12V to 24V. There is a soft power on/off function that retains memory of the indicator's state. Once an instrument is turned on it will automatically start up again if the external power is interrupted.

The instrument is fitted with opto-LINK communications as standard. This allows a temporary isolated communications link to be established with a PC using an opto-LINK cable, which enables software upgrades and the use of computerised setup and calibration via the Viewer software. Refer to opto-LINK (Optional) page 15 for more information.

1.1. Overview

This instrument provides **ZERO** and **TARE** functionality as well as more setup options (eg. serial and setpoints) and printing functionality.

It also supports special functions (eg. peak-hold, live weight (livestock) averaging, counting, etc.), via the user definable **<FUNCTION>** key. It is equipped with an NVRAM store to ensure day-to-day operating settings (eg. **ZERO**, **TARE**, **CLOCK**, etc.), are retained when power is removed.

This instrument has three isolated transistor outputs with status display and LEDs on the front panel as well as the RS-232 communications port that can be used for

printer driving or connection to a remote display or PC. There is a built-in clock for date-stamping printed outputs.

1.2. Approvals

C-tick approved and CE approved.

1.2.1. Trade versions

- NSC approval (4000 divisions at 0.8 μ V/division).
- NMI approval (4000 divisions at 0.8 μ V/division).
- NTEP approval (10000 divisions at 0.8 μ V/division).

1.3. The Manuals Set

This manual is part of a set of manuals covering the setup and operation of the instrument. The set includes the following:

- **Reference Manual** - Contains detailed information on calibration and setup. This manual is intended for use by Scale Technicians who are installing the instrument.
- **Operator Manual** - Aimed at the operator of the instrument, and covers the day-to-day operation of the instrument.
- **Quick Start Manual** - Intended for Scale Technicians who are familiar with the instrument and simply need a quick reference to menu options and connection diagrams, etc.
- **Communications Manual** - Contains details on the extended networking capabilities (communications protocol).

1.4. Document Conventions

The following document conventions (typographical) are used throughout this Reference Manual.

Bold Text	Bold text denotes words and phrases to note.
<Key>	<Key> denotes a Keypad key. Note: In the Specifications section the < symbol means less than and the > symbol means greater than .
^	This symbol denotes one space
⊗	Items marked with ⊗ indicate that the setting is available only in Full Setup and is trade critical. When trade critical settings are changed the calibration counter will be incremented.

2. Specifications

Performance		
Resolution	Up to 30,000 divisions, minimum of 0.25 μ V/division. (K307 up to 60,000 divisions)	
Zero Cancellation	± 2.0 mV/V	
Span Adjustment	0.1mV/V to 3.0mV/V full scale	
Stability/Drift	Zero: < 0.1 μ V/ $^{\circ}$ C (+ 8ppm of deadload max) Span < 8 ppm/ $^{\circ}$ C, Linearity < 20ppm, Noise < 0.2 μ Vp-p	
Excitation	5 volts for up to 4 x 350 or 8 x 700 ohm load cells (4-wire or 6-wire plus shield) Maximum total load cell resistance: 1,000 ohms	
A/D Type	24bit Sigma Delta with 8,388,608 internal counts	
A/D Conversion Rate	20Hz with FIR filtering > 80dB	
Operating Environment	Temperature: -10 to +50 $^{\circ}$ C ambient Humidity: 100% Storage: -20 to +50 $^{\circ}$ C ambient IP69K	
Case Materials	PC+Polyester alloy, PBT, Silicon Rubber, SS304 Stand	
Packing Weights	Basic Indicator: 2.0kg	
Digital		
Display	LED Backlit LCD with six 20mm high digits with units and annunciators	
Setup and Calibration	Full digital with visual prompting in plain messages	
Digital Filter	Sliding window average from 0.1 to 4.0 seconds	
Zero Range	Adjustable from $\pm 2\%$ to $\pm 100\%$ of full capacity	
Power Input		
Standard Power Input	12 to 24VDC, 9.6, 12 and 24V batteries (2.5 VA max) – ON/OFF key with memory feature	
Variants	AC	AC Power supply: 110/240VAC 50/60Hz in 24VDC 1.25A out
	Battery	12V battery pack (2.5Ah rechargeable NiMH)
Features		
opto-LINK Data Coupling	Infra-red Connector for optional opto-LINK PC cable (to RS-232 or USB PC port)	
Correction	Ten point linearity correction (K304 Only)	
Outputs	RS-232 automatic transmit, network or printer outputs. Transmission rate: 2400, 4800 or 9600 baud	
Assignable Function Key	Unit switching, counting, manual hold, peak hold, live weight, totalising	
Drive Outputs	3 isolated high side drive outputs (400mA each at 12-24VDC)	
Battery Backed Clock Calendar	Battery life 10 years minimum	

3. Installation

3.1. Introduction

The following steps are required to set up the indicator.

- Inspect indicator to ensure good condition.
- Use connection diagrams to wire up load cell, power and auxiliary cables as required.
- Connect Power to indicator and press **<POWER>** key to turn the instrument on.
- Refer to the Accessing Setup section page 30 for information on configuring and calibrating the instrument.
- To turn instrument off press and hold **<POWER>** key for three seconds (until display blanks).

3.2. General Warnings

- Indicator not to be subject to shock, excessive vibration or extremes of temperature (before or after installation).
- Inputs are protected against electrical interference, but excessive levels of electro-magnetic radiation and RFI may affect the accuracy and stability.
- The instrument should be installed away from any sources of excessive electrical noise.
- The load cell cable is particularly sensitive to electrical noise and should be located well away from any power or switching circuits.
- For full EMC or for RFI immunity, termination of cable shields and correct earthing of the instrument is essential.
- Indicator and load cell cable are sensitive to excessive electrical noise. Install well away from any power or switching circuits.

3.3. Electrical Safety

- For your protection all mains electrical hardware must be rated for environmental conditions of use.
- Pluggable equipment must be installed near an easily accessible power socket outlet.
- To avoid the possibility of electric shock or damage to the instrument, always switch off or isolate the instrument from the power supply before maintenance is carried out.

3.4. Cleaning

- The unit has been designed for high-pressure, high temperature (80°C) wash-down environments. However long periods of focused pressure at a close range will damage the casing. Casing is chemical resistant.

3.5. Cable Connections

All cable connections are made to the rear of the instrument using pluggable screw terminals. It is not necessary to tin the ends of the wire with solder or to add crimp ferrules to the wires, however, these techniques are also compatible with the terminals and may ultimately make for a neater job.

LOAD CELL CONNECTIONS





Figure 2: Cable Connections

3.6. DC Power (DC PWR + , DC PWR –)

The DC supply need not be regulated, provided that it is free of excessive electrical noise and sudden transients. The instrument can be operated from a high quality plug-pack as long as there is sufficient capacity to drive both it and the load cells.

If an optional battery pack is fitted, then the supplied charging system must be used.

3.7. Load Cell Connection

3.7.1. Load Cell Signals and Scale Build

Very low output scale bases may be used but may result in some instability in the weight readings when used at higher resolutions. Generally speaking, the higher the load cell output, or the lower the number of divisions, the greater the display stability and accuracy.

The instrument can display the milliVolt-per-Volt reading that can be used to check scale base signal output levels. For more information, refer to SCALE

(Scale Base Test Display) page 40.

The instrument may be connected for either 4-wire or 6-wire operation. To correspond with the actual cabling installation the instrument must be configured in setup to the correct setting. For more information, refer to CABLE (4-Wire or 6-Wire) ⊗ page 33.

3.7.2. 4-Wire Connection

The minimum connectivity requirements are the connection of four wires (ie. Excitation + and – along with Signal + and –). Internally the instrument has a precision analogue switch that connects the Sense + and – lines directly to the Excitation + and – lines when 4-wire mode is selected.

A 4-wire connection is only suitable for short cable runs. Where long cable lengths are needed, a 6-wire extension is required to maintain accuracy.

The BUILD:CABLE option must be set to **4** to allow for 4-wire connection. Refer to CABLE (4-Wire or 6-Wire) ⊗ page 33.




Figure 3: 4-Wire Connections

3.7.3. 6-Wire Connection

The excitation and signal lines are connected the same as for a 4-wire installation. The extra two wires (Sense + and –) should be connected to the Excitation + and – lines as close as possible to the load cell itself. Typically these connections are made in a load cell termination box.

The BUILD:CABLE option must be set to **6** (the default) to allow for 6-wire connection. Refer to CABLE (4-Wire or 6-Wire) ⊗ page 33.




Figure 4: 6-Wire Connections

3.8. Auxiliary Connections

This section provides diagrams to illustrate the terminal connections.

3.8.1. RS-232 Serial

Network: One Instrument to PC (RXD, TXD, GND)




Figure 5: RS-232 – One Instrument to PC using COM Port (DB9)




Figure 6: RS-232 – One Instrument to PC using COM Port (DB25)

Ring Networks: Multiple Instruments to PC (RXD, TXD, GND)

Instruments can be configured in a Ring Network

The Short Ring Network layout can be used in situations up to a total cable run length of about 150 m (500 ft) at 9600 baud in a clean EMC environment. If there are communications errors, or for longer cable runs, lower the baud rate to 4800 or 2400, and/or use the Long Ring Network in Figure 8 below, which uses a separate return path from the 'Last Instrument' to the PC.

For DB25 connections at the PC connector, refer to Figure 6 above.

When operating in a Ring Network, the Instruments must have:

- **same** serial port options, i.e., baud, parity, data bits, stop bits;
- **unique** addresses.

Short Ring Network: Multiple Instruments to PC (RXD, TXD, GND)




Figure 7: RS-232 Short Cable Runs: Ring Network using COM Port (DB9)

Long Ring Network: Multiple Instruments to PC (RXD, TXD, GND)

The Long Ring Network layout can be used in situations where each leg of the cable run can be up to about 150 m (500 ft) at 9600 baud. If there are communications errors, lower the baud rate to 4800 or 2400.




Figure 8: RS-232 Long Cable Runs: Ring Network using COM Port (DB9)

Printer Connections (RXD/TXD, GND and DTR)




Figure 9: RS-232 – Instrument to Printer (DB25)

Remote Display (TXD, GND)

The remote display documentation should be referred to for connection details. Connect TXD to RXD and GND to GND on the remote display.

3.8.2. Remote Input

The indicator requires a voltage free contact between TXD and RXD to enable the remote input (ie. SPEC:REM.FN). The SERIAL:FORMATTYPE option must be set to AUTO1, AUTO2,, PRINT or MASTERAUTO.PR. When using SERIAL:TYPE of PRINT or AUTO.PR, the SPEC:REM.CHR must be set to an appropriate character that will not affect the printer. This character will be sent repeatedly when the transmitter is idle, regardless of the state of the DTR line.

Note: The remote input will not function when in setup or when using the opto-LINK.




Figure 10: Remote Input

WARNING

The remote input is a voltage free contact (eg. button, mechanical relay). Connection of any active circuitry may damage the instrument.

3.8.3. Outputs

The output drivers for the instrument are high side drive and are capable of driving up to 400mA each. This configuration allows for the direct connection of the instrument outputs to most types of PLC.

The voltage applied to the instrument's positive power supply terminal (+) appears on the output lines (Over, Pass and Under) when the outputs are active. The outputs can then be connected directly to PLC inputs.

To drive external loads (eg. relays), connect the output line directly to the positive side of the relay coil. Connect the negative side of the relay coil to COMMON. It is recommended that fly-back diodes or transient suppressors be fitted across inductive loads such as relay coils to limit switching noise.




Figure 11: Instrument Outputs to Drive Relay




Figure 12: Instrument Outputs to Drive PLC

3.9. opto-LINK (Optional)

A temporary infrared communications link can be established between the instrument and a PC using an optional opto-LINK cable. The optional opto-LINK cable can be used to transfer setup and calibration information from a PC (eg. to be stored for later use and/or transferred to other instruments). It can also be used to download software upgrades to the instrument from a PC.

The PC end of the opto-LINK cable is a standard female DB9 connector, or USB connector. The instrument end of the cable consists of an infrared transceiver, which attaches to the left side of the instrument display. To facilitate a quick and simple connection, the infrared transceiver is secured in place by a permanent magnet located within the head of the opto-LINK.

Refer to opto-LINK Activation page 24 for more information.

WARNING

The opto-LINK head contains a strong magnet and care should be taken with its proximity to electronic media (eg. credit cards, floppy disks, etc.) and/or other electronic instrumentation.



Figure 13: opto-LINK Attachment

3.10. Connecting Shields

To obtain full EMC or for RFI immunity, cable shields **MUST** be connected to the earth lug on the rear of the instrument.

3.10.1. Cable Shield Connection and Earthing

- Care should be taken when connecting shields to maximise EMC or RFI immunity and minimise earth loops and cross-talk (interference) between instruments.
- For full EMC or for RFI immunity, termination of the cable shields at the earth lug is very important. The earth lug of the instrument must be separately connected to ground potential via a reliable link.
- The instrument should only be connected to earth via a single reliable link to avoid earth loops.
- Where each instrument is separately earthed, interconnecting cable shields should be connected at one end only. This also applies to communications cable shields in Ring Networks, refer to Short Ring Network and Long Ring Network connections under 'RS-232 Serial' pages 11 and 12.
- **Caution:** Some load cells connect the cable shield directly to the load cell (and therefore the scale base). Connection of the load cell cable shield in this situation may be site specific.

3.11. Regulatory Sealing Requirements

To comply with regulatory sealing requirements for each instrument, (ie. to ensure instruments are not accidentally or deliberately tampered with), it is important that proper sealing procedures be adhered to. Refer to Sealing page 58 for more information.

4. Data Entry

Throughout the setup and normal weighing mode, different data entry methods are used. Each method is described below.

When using the keypad for normal operation, press the key on keypad to initiate the feature.

4.1. Editing Annunciators

When in Setup the instrument displays editing annunciators. Figure 14 identifies each of the editing annunciators. When in Setup, press the corresponding keypad key below the annunciator.




Figure 14: Editing Annunciators

Editing Annunciator	Key Name	Description
GRP	ZERO	Steps through the list of Groups.
ITM	TARE	Steps through the list of Items. Press this key to accept changes and return to the menus. (Also refer to the OK description below.)
SEL	GROSS/NET	Moves the editing cursor in some editing modes.
EDT	PRINT	Steps through the available options when editing a particular item.
OK	OK (FUNCTION)	Press this key to accept changes and return to the menus. (Also refer to the ITM description above.)

4.2. Numeric Entry

A numeric entry box allows the input of a number. When entering a number, the display will show digits with the currently selected digit flashing. The **<SEL>** key is pressed to select a digit to change. When the digit is selected the **<EDT>** key is pressed to change the digit from **0** through **9**. The left most digit can also be changed to a dash (-) to enter a negative number. The **<OK>** key is pressed to accept the number that has been entered and return to the menu item.

Upper and lower limits are placed on some entries and an entry outside this range will cause the instrument to display dashes (ie. - - - - -).

Example: When in Setup follow the steps below to set Build, Max Capacity.

Press <GRP> repeatedly to display the BUILD group.
Press <ITM> repeatedly to display the CAP item.
Press <SEL> to select CAP and display the current setting (eg. 0000.00kg).
The currently chosen digit will be flashing. Press <SEL> to advance to the next digit.
When the digit to edit is flashing, press <EDT> repeatedly to cycle from 0 through 9 .
When the new digit to be set is flashing either press <SEL> to move to the next digit to edit and repeat the previous step; or press <OK> or <ITM> to accept all of the displayed digits (including the flashing digit) and re-display the menu item name.

4.3. Selections and Options

A selection entry requires the choice of a single option from a list. When a Group and Item have been chosen, the **<SEL>** key is used to display the current setting for that item. The **<EDT>** key can be used to cycle through the options for that item. When the desired option is displayed the **<OK>** key can be pressed to accept the displayed option and re-display the item name.

Example: When in Setup follow the steps below to set Options, Filter.

Press <GRP> repeatedly to display the OPTION group.
Press <ITM> repeatedly to display the FILTER item.
Press <SEL> to select FILTER and display the current setting.
Press <EDT> to cycle through the options for that item.
Press <OK> or <ITM> to accept the displayed option and re-display the menu item name.

5. Basic Operation

In the most basic configuration, the instrument provides a simple weight readout.

5.1. Display and Controls




Figure 15: Display and Controls Illustration

5.1.1. Front Panel: Visual Display

The front panel has a six-digit LCD display. Figure 15 shows the main elements of the front panel.

The instrument has various main display sections for the visual output of weight information. Each display section is described below.

Weight Display

The Weight Display indicates the weight readings, setup information, errors and warnings.

Units Display

The Units Display shows the units of the weight reading as either grams (g), kilograms (kg), pounds (lb), tonnes (t) or none. If the instrument is set up for counting the units display will show pieces (p).

Status Annunciators

Status annunciators show the following:

Symbol	Name	Description
	ZERO	Visible when the gross reading is within $\pm \frac{1}{4}$ of a division of true zero.
	NET	Visible when the displayed reading represents NET weight.
	MOTION	Visible when the displayed reading is not stable.
	OVER	Visible when check weighing is enabled and the weight is above the target weight.
	UNDER	Visible when check weighing is enabled and the weight is below the target weight.
	PASS	Visible when check weighing is enabled and the weight is between the target weights.
1	RANGE 1	Visible when dual range is enabled and range 1 is active. (K306 only.)
2	RANGE 2	Visible when dual range is enabled and range 2 is active. (K306 only.)
	ZERO BAND	Visible when the displayed weight is within the zero 'dead' band setting. (The zero band symbol shows near the top right corner of the display.)
	HOLD	Visible when the displayed reading is held.
	LOW BATTERY	Visible when battery voltage is too low and batteries need replacing or recharging. (The low battery symbol shows in the top right corner of the display.)

Table 1: Status Annunciators

When in Setup the editing annunciators are shown to identify the function of the front panel keys (ie. **GRP**, **ITM**, **SEL**, **EDT** and **OK**). For more information refer to Editing Annunciators page 18.

5.2. Operation Keys

The instrument has the following operation keys:

POWER
Primary Operation Keys
ZERO
TARE
GROSS/NET
PRINT
FUNCTION (user defined)

Each of the primary operation keys has two separate functions.

5.2.1. Primary Function

A single press of each key triggers the weighing operation printed on it. The instrument allows individual keys to be disabled in the setup. All keys are enabled at the factory, but some keys may have been intentionally disabled (locked) during installation. If a key has been locked, a long beep sounds when it is pressed. If

however, the key beeps normally, but does not appear to trigger the desired action, it is waiting for the weight reading to settle before the action can proceed.

5.2.2. Editing Function

Available during digital setup and calibration. This function is displayed using the editing annunciators above each key. Refer to Editing Annunciators page 18.

5.3. Stability Considerations

Once a **<ZERO>**, **<TARE>** or **<PRINT>** key is pressed the instrument waits for a stable valid reading before performing the associated operation. If the weight readings remain unstable or invalid due to some diagnostic error for longer than 10 seconds, the operation is cancelled and the **STABLE ERROR** message is displayed.

To improve the stability of the weight reading, increase the filtering or relax the motion detection criteria. Refer to FILTER

(Reading Average) page 34 and MOTION

(Motion Detection) ⊗ page 34 for more information.

5.4. POWER Key



The **<POWER>** key is used to turn the instrument on and off. To initially turn the instrument on, press and hold the **<POWER>** key. The display will show the following:

- Display segments will light and then clear.
- Software Version (eg. V1.0).
- Calibration Counter (eg. C.00010). Refer to Calibration Counter page 28 for more information.
- The current weight will then display.

To turn the instrument off, press and hold the **<POWER>** key for three seconds. The instrument will display **OFF** followed by the three-second countdown.


When using batteries the backlight will automatically turn off to conserve power after a short period of inactivity. Motion or a short press of the **<POWER>** key will turn the backlight on again. Refer to B.LIGHT (Backlight Operation) page 37 for more information.

Note: The **<POWER>** key can be locked to prevent the instrument being turned off from the front keypad. Refer to KEY.LOC (Front Panel Key Locking) page 36 for more information.

5.4.1. Automatic Operation

The **<POWER>** key on the instrument is unusual in that it has a memory function associated with it. This means that the state of the power setting is remembered even if external power is interrupted. It is therefore possible to turn the instrument on in the safe knowledge that it will operate whenever external power is available and will not need to be manually turned on again if the power is interrupted.

5.5. ZERO Key



When an empty scale has drifted away from a true zero reading, this key is used to perform a zero adjustment on the scale display. The zero adjustment is stored when power is removed and is re-used when next powered up.

The amount of weight that may be cancelled by the **<ZERO>** key is limited via an item in the Setup of the instrument. Refer to Z.RANGE (Allowable Zero Operating Range) ⊗ page 34 for more information.

Long Press: When the indicator is set to Industrial mode a long press of the **<ZERO>** key will remove any stored zero adjustment. Refer to Industrial vs NSC, OIML and NTEP Modes page 28 for more information on modes.

5.6. TARE Key



This key is used to temporarily set the scale to zero (such as cancelling the weight of a carton before performing a filling operation). The display will show the Net weight and the NET annunciator will be lit.

The **<TARE>** key can operate in all modes (ie. Industrial, NSC, OIML and NTEP). Refer to Industrial vs NSC, OIML and NTEP Modes page 28 for more information.

The weight tared is deducted from the allowable range of the scale, reducing the maximum weight that can be displayed.

The tare adjustment is stored when power is removed and is re-used when next powered up.

5.6.1. Preset Tare

This feature enables the user to manually enter the tare weight. When there is a preset tare weight being used the instrument will display **Pt** before displaying the net weight.

Any printing of the tare weight will be followed by the letters **Pt** if a preset tare value is active.

A long press of the **<TARE>** key will allow editing of the preset tare value. Press the **<OK>** key to enter the Preset Tare setting. Change the Preset Tare setting using the **<SEL>** and **<EDT>** keys.

The Preset Tare setting can be cleared by one of two means:

- using a long press of the **<TARE>** key and editing the preset tare value to zero.
- While the gross load is zero;
 - Using a short press of the **<TARE>** key to retare the instrument in the usual manner.
 - OR, Using a short press of the **<ZERO>** key to zero the instrument in the usual manner.

The tare adjustment is stored when power is removed and is re-used when next powered up.

5.7. GROSS/NET Key



This key toggles the weight display between the Gross weight and the Net weight (provided that a Tare has previously been acquired using the **<TARE>** key).

5.8. opto-LINK Activation

This feature is used to temporarily connect a PC to the instrument for calibration and setup purposes.

A long press of the **<GROSS/NET>** key will toggle the opto-LINK infrared communications On/Off.

When the opto-LINK has been (enabled) the following will occur:

- The instrument briefly displays the prompt **opto-L**.
- The editing annunciators (ie. GRP, ITM, etc.) will flash for up to five minutes while the instrument searches for activity. During this period, the instrument also disables the RS-232 communications.
- After a 5 minute period with no activity, the opto-LINK will be disabled and the editing annunciators will stop flashing. The instrument will also revert back to normal RS-232 communications (ie. The SERIAL:TYPE setting will be re-activated).

5.9. PRINT Key



If a printer or computer has been attached to the instrument and the manual print function has been selected, the **<PRINT>** key will trigger an output of the current weight reading. The **PRINT** prompt is displayed while waiting for the printer to accept data. If the printer is offline the **PRINT** prompt will remain for a maximum of 10 seconds before the operation is cancelled. Each weight printed is automatically added to an internal Total Weight.

Long Press: A long press of the **<PRINT>** key will print the total. The total weight is then cleared automatically.

5.10. FUNCTION Key



When leaving the factory, the **<FUNCTION>** key is blank and has no primary function pre-programmed. The primary function of this key can be selected from a number of different functions including peak-hold, counting, etc. Refer to Special Functions page 53 for details of the available functions. Each primary function has an associated overlay sticker that should be applied to the **<FUNCTION>** key to label the function of the key.

Long Press: A long press of the **<FUNCTION>** key may be used for certain functions depending on the primary function of the key.

6. Configuration

6.1. General Setup Information

Configuration and calibration can be performed entirely from the front panel, using the digital setup facility. When **Full Setup** is used, all menu items are accessible and care must be taken to ensure no accidental changes are made to calibration and trade settings. In addition, there is also **Safe Setup** that provides restricted access. This setup method ensures that only settings that are not calibration or trade sensitive can be changed.

Full and Safe Setup can be passcode protected to prevent unauthorised or accidental tampering. If the scale has been passcode protected, the setup menus cannot be accessed until the correct code has been entered.

6.2. Basic Weighing Terminology

The following terms are used throughout the setup procedure. Knowledge of these basic weighing terms is beneficial in setting up and calibrating the instrument.

Note: Descriptions of these and other terms used in this manual are listed in the Glossary Terms page 64.

Term	Definition
Units	Units of measurement (kilograms, tonnes, pounds, etc.).
Full Scale	Total change in weight between zero gross load and full capacity gross load.
Resolution or Count-by	Smallest change in weight units that the display can show.
Total Number of Graduations	Maximum number of display steps between zero gross load and full capacity gross load. It is equal to full scale divided by the count-by.
Division	A single graduation.

Example

This example provides a check to ensure the capability of an indicator to read a stable weight on extremely small divisions compared to the load cell capacities.

The check is to find out what the microvolt per division is and then compare this to the manufacturer's specification. If the manufacturer's specification is smaller than the calculated value, the unit is within the requirements of operation.

Note: The capability of an indicator may be different than the trade approval limit of the micro-Volt per division.

A 10,000kg 2.0mV/V load cell is used in an application requiring a 5000kg full scale, with weight displayed in 5kg increments.

The values are:

- Units = kg
- Full Scale = 5000
- Count-by = 5

Calculating the total number of graduations:	Total Number of Graduations = $\frac{\text{Full Scale}}{\text{Count-by}} = \frac{5000}{5} = 1000$ divisions
Signal voltages can be calculated as follows:	
Calculating the full scale signal (load cell):	Full Scale Signal = $\frac{\text{Full Scale}}{\text{Load Cell Capacity}} = \frac{5000}{10000} \times 2.0\text{mV/V} = 1.0\text{mV/V}$
Since the instrument uses 5V load cell excitation, the absolute signal voltage is:	Absolute Signal Voltage = Excitation Voltage x Full Scale Signal = $5\text{V} \times 1.0\text{mV/V} = 5.0\text{mV}$
Calculating the signal resolution:	Signal Resolution = $\frac{\text{Absolute Signal Voltage}}{\text{Number of Graduations}} = \frac{5.0\text{mV}}{1000 \text{ divisions}} = 0.005\text{mV / division} = 5\mu\text{V / division}$

6.3. Dual Range Operation (K306 only)

A dual range mode of operation is available as well as the traditional single range setting. When the Full Scale of Range1 is less than Full Scale, dual range is automatically enabled.

In non-trade operation, up to 30,000 divisions are available (60,000 for K307) so it is rare for the precision of the displayed reading to be a problem. However, in trade applications where the number of divisions that can be legally displayed is limited, the use of dual range operation allows greater precision in the displayed readings without exceeding the maximum number of graduations available in the certification of the load cell.

This mode of operation allows for operation with fine increments for a low weight range, and coarse increments in a high range.

Example

This example provides checks to ensure the capability of an indicator, in dual range mode, to read a stable weight on extremely small divisions compared to the load cell capacities.

The check is to find out what the microvolt per division is and then compare this to the manufacturer's specification. If the manufacturer's specification is smaller than the calculated value, the unit is within the requirements of operation.

Note: In principle, each range should be treated as a separate instrument. Signal resolution should be checked for each range.

A 10kg 2.0mV/V C3 load cell is used with a minimum loadcell verification interval of 1μV. The application requires 3kg in 1g increments and up to a 6kg full scale using 2g increments.

The values are:

- Units = kg
- Full Scale = 6000
- Decimal point = 0.000
- Count-by = 1
- Graduations = 3000

The number of graduations is selected to meet the requirements of both the loadcell and instrument.	
Calculating the Range 1 Full Scale (Choose the smaller number as result)	$\text{Full Scale}_{\text{Range1}} = \text{Lessor of } \frac{\text{Full Scale}}{\text{Resolution} \times \text{Number of Graduations}} = \text{Lessor of } \frac{6000}{1 \times 3000} = 3000$
Since $\text{Full Scale}_{\text{Range1}}$ is less than Full Scale, dual range is enabled.	
For Range 1: (Signal voltages can be calculated as follows)	
Calculating the full scale signal (load cell):	$\text{Full Scale Signal}_{\text{Range1}} = \frac{\text{Full Scale}_{\text{Range1}}}{\text{Load Cell Capacity}} = \frac{3000}{10000} \times 2.0\text{mV/V} = 0.6 \text{ mV/V}$
Since the instrument uses 5V load cell excitation, the absolute signal voltage is:	$\text{Absolute Signal Voltage}_{\text{Range1}} = \text{Excitation Voltage} \times \text{Full Scale Signal}_{\text{Range1}} = 5\text{V} \times 0.6\text{mV/V} = 3.0\text{mV}$
Calculating the signal resolution:	$\text{Signal Resolution} = \frac{\text{Absolute Signal Voltage}}{\text{Number of Graduations}} = \frac{3.0\text{mV}}{3000} = 0.001\text{mV/division} = 1\mu\text{V/division}$
Check that the signal resolution is sufficient to meet the requirements of both the loadcell and instrument.	
For Range 2: (Total number of Graduations can be calculated as follows)	
The Resolution will be the next greatest from Range1 choice (Count-by=1):	$\begin{aligned} \text{Resolution}_{\text{Range1}} &= 1 \\ [1, 2, 5, 10, 20, 50, 100, 200] \\ \text{Resolution}_{\text{Range2}} &= 2 \end{aligned}$
Calculating the total number of graduations for Range 2	$\text{Total Number of Graduations} = \frac{\text{Full Scale}}{\text{Resolution}_{\text{Range2}}} = \frac{6000}{2} = 3000 \text{ divisions}$
Check that the number of graduations for range 2 meets the requirements of both the loadcell and instrument.	

6.4. Gravity Compensation (K306 Only)

If there is a difference in gravitational acceleration between the factory (where the scale is calibrated) and the installed location, then weighing errors can occur. The Gravity Compensation feature uses a factory and installation gravity setting to adjust the weight reading and prevent errors.

If the scale is calibrated at the installation location then it is not necessary to use the Gravity Compensation feature. Refer to section 9.4 Using Gravity Compensation.

6.5. Accumulation Mode (K307 Only)

K307 uses 'accumulation mode' to enable and disable totalising. This defaults to off. Totalising will not occur until accumulation mode has been enabled. This is achieved by pressing <POWER> and <PRINT> together for 2 seconds. The display will show "ACC" "ON" or "ACC" "OFF".

6.6. Filtering Techniques

There is a trade off between noise filtering and the step-response time of the system. The step-response is defined as the time between placing a weight on the scale and the correct stable weight reading being displayed. This does not affect the number of readings per second that are taken. It simply defines the amount of time that is required to determine a final weight reading.

The **FILTER** setting in the instrument setup shows the amount of time over which the averaging is taken. Increasing the averaging time will result in a more stable reading but will extend the time it takes the instrument to settle to a final reading. Refer to **FILTER**

(Reading Average) page 34.

6.7. Industrial vs NSC, OIML and NTEP Modes

Instruments may be operated in Industrial, NSC, OIML, or NTEP modes depending on the application software version. K304 and K306 software allow operation in Industrial, NSC, or OIML modes. K307 software allows operation in Industrial, or NTEP modes. The NSC, OIML, and NTEP modes restrict certain aspects of the operation of the instrument to ensure compliance with the respective trade certified standards. For more information refer to the Calibration Counter section below and also to the **USE**

(Scale Use) ⊗ section page 34 for setup information. The following table lists the operation differences for each of these modes.

Element	Industrial	NSC	OIML	NTEP
Underload	–105% of full scale	–1% or –2% of full scale depending on zero range setting	–1% or –2% of full scale depending on zero range setting	–1% or –2% of full scale depending on zero range setting
Overload	105% of full scale	Full scale +9 divisions	Full scale +9 divisions	105% of full scale
Tare	No restrictions on Tare	Tare values must be > 0	Tare values must be > 0	Tare values must be > 0 and rounded to the nearest graduation
Test Modes	Unlimited time allowed	Limited to five seconds	Limited to five seconds	Limited to five seconds

Table 2: Industrial vs NSC, OIML and NTEP Modes

6.8. Calibration Counter

Within the setup there are a number of critical steps that can affect the calibration and/or legal for trade performance of the instrument. If any of these steps are altered, the trade certification of the scale could be voided.

The instrument provides built-in calibration counter(s) to monitor the number of times the critical steps are altered. The value of a counter is stored within the instrument and can only be reset at the factory. Each time a critical step is altered, the counter will increase by one. Whenever the instrument is powered up, or setup mode is entered/exited, the current value in the counter is displayed briefly (eg. C00010).

Note: When the Scale Use is set to NTEP two counters will display. Refer to USE (Scale Use) ⊗ page 34 for setup information. The table below describes when the counter(s) will increment for Industrial, NSC, OIML, or NTEP modes.

Industrial	NSC	OIML	NTEP
The Calibration Counter increments when trade critical settings, marked with ⊗, are changed. An example of the counter is C.00019 .	The Calibration Counter increments when trade critical settings, marked with ⊗, are changed. An example of the counter is C.00019 .	The Calibration Counter increments when trade critical settings, marked with ⊗, are changed. An example of the counter is C.00019 .	The Calibration Counter increments when trade critical settings in the Calibration (CAL) menu, marked with ⊗, are changed. An example of the counter is C.00010. The Configuration Counter increments when other trade critical settings (ie. not in the CAL menu), marked with ⊗, are changed. An example of the counter is F.00009.

The value(s) of the counter(s) is written on the tamperproof trade label on the front or top of the indicator for trade-certified applications and functions as an electronic seal. If any legal for trade settings are changed on the instrument, the current value of the calibration counter will be different from the recorded value and the seal is broken. In this manual, items marked with ⊗ indicate that the setting is legal for trade critical settings.

6.9. Passcodes

The instrument has two levels of passcodes to provide a security lock on accessing Setup via the keypad.

- Full Setup Passcode
- Safe Setup Passcode

The Full Setup passcode can also be used to access Safe Setup.

6.9.1. Full Setup Passcode

Setting a passcode for Full Setup restricts any access to Full Setup. Refer to FULL.PC (Full Security Passcode for Digital Setup) page 36.

6.9.2. Safe Setup Passcode

Setting a passcode for Safe Setup restricts access to Safe Setup functions. Refer to SAFE.PC (Safe Security Passcode for Digital Setup) page 36.

6.9.3. Setup Lock-Out

If an attempt is made to enter Full or Safe Setup using an incorrect passcode, the instrument will respond with the message **ENTRY DENIED** and then the user will be returned to normal operating mode. A passcode counter has been set so that only three failed attempts can be made to access Full/Safe Setup. On the fourth attempt the user will be 'locked out' of Full/Safe setup. Should this occur the **ENTER PASS** prompt will not display, but instead the **ENTRY DENIED** message displays and returns the user to the normal operating mode. To rectify this issue the instrument must be turned off. When the instrument is turned back on the passcode counter is reset to zero (allowing the user to enter the correct passcode).

7. Accessing Setup

The instrument digital setup facilities provide the means to configure and calibrate the instrument.

7.1. Accessing Setup

There are two methods to access the Setup area. For further details of menu items available in each setup mode, refer to the Setup Menu Quick Reference page 59.

7.1.1. Full Setup

The Full Setup method provides access to all functions in Setup, including legal for trade and calibration sensitive settings. Changes in Full Setup mode may result in the calibration counter being incremented. Items marked with ⊗ indicate that the setting is trade critical. Changes to passcodes and restoring the factory default settings can only be accessed in Full Setup mode. These items will however not increment the calibration counter. If an attempt is made to enter Full Setup using the incorrect passcode, the instrument will respond with the message ENTRY DENIED. Refer to Passcodes page 29 for more information.

Full Setup	
 POWER + GROSS / NET	To access Full Setup, first ensure the instrument is on. Then press and hold both the <POWER> and <GROSS/NET> keys together for two seconds. Full Setup can also be entered by pressing a push-button accessed from the rear of the instrument. Refer to OPTIONS:R.ENTRY page 34 for more details.

WARNING

All items in all menus will be enabled in Full Setup. Care should be taken to avoid inadvertently altering the Build or Calibration settings

7.1.2. Safe Setup

The **Safe Setup** method restricts access to the Trade Critical settings. Changes made in this mode will not increment the calibration counter. In this manual, items marked with ⊗ indicate that the setting is trade critical. If an attempt is made to enter Safe Setup using the incorrect passcode, or if an attempt is made to alter a trade critical setting while in Safe Setup, the instrument will respond with the message **ENTRY DENIED**. Refer to Passcodes page 29 for more information.

Safe Setup	
 POWER + TARE	To access Safe Setup, first ensure the instrument is on. Then press and hold both the <POWER> and <TARE> keys together for two seconds.

7.1.3. Setup Display Prompts

When accessing **Full** or **Safe Setup** the instrument will beep twice and then display the following:

- FULL or SAFE (depending on setup access type)
- SETUP
- Software Version (eg. V1.0)
- Calibration Counter (eg. C.00010). Refer to Calibration Counter page 28 for more information
- If a passcode has been configured, the **ENTER PASS** prompt will display and the setup passcode must be entered to gain access. Refer to Passcodes page 29, SAFE.PC (Safe Security Passcode for Digital Setup) page 36 and FULL.PC (Full Security Passcode for Digital Setup) page 36 for more information.
- The title of the first Group (ie. **BUILD**) will then be displayed.

7.2. Exiting Full or Safe Setup

To save settings, exit setup and return to the normal weighing mode use one of the following methods:

Method 1: Press and hold both the <POWER> and <GROSS/NET> keys together for two seconds.
Method 2: Press and hold both the <POWER> and <TARE> keys together for two seconds.
Method 3: Press the <GRP> key repeatedly. When - End - displays press <ITM> or <OK> .

The instrument will beep and then display the following:

- SAVING
- Software Version (eg. V1.0)
- Calibration Counter (eg. C.00010). Refer to Calibration Counter page 28 for more information.
- The current weight will then display.

Warning: If the power is interrupted while in setup (ie. by disconnecting the power cable or pressing the **<POWER>** key), unsaved settings will be lost.

8. Setup Menus

8.1. Groups and Items

All keypad setup options in the instrument are organised in a tree structure made up of **Groups** and **Items**. To simplify this document, Groups and Items will be notated as follows (GROUP:ITEM). Refer to Setup Menu Quick Reference page 59 for a list of all Groups and Items.

8.1.1. GRP (Group)

Setup is divided into a series of **Groups**. Each group has a distinctive group title. All options in any one group have related functions. The **<GRP>** key can be used to cycle through the available groups.

8.1.2. ITM (Item)

Each group is divided into individual **Items**. Each item represents a parameter that can be changed. Pressing the **<ITM>** key will enter the displayed group, allowing access to the items within the group. The **<ITM>** key can be used to cycle through the available items. The **<SEL>** key is then used to edit the item.

8.2. Setup Menus

The following sections describe the setup parameters of each of the Groups and Items in Setup.

8.2.1. BUILD (Scale Build)

Settings within this Group are used to configure the indicator to suit the current application. It is important to fully set the options within this group before calibration is attempted. Later changes to items within this group may invalidate the current calibration data.

DP (Decimal Point Position) ⊗	Sets the location of the decimal point on the display. To avoid confusion, set this parameter first so that all other weight related values are displayed with the decimal point in the correct position.	Can be set from 000000 (none) to 0.00000 Default: 000000
CAP (Maximum Capacity) ⊗	Sets the nominal maximum capacity (or full scale) of the scale. This is set in weighing units (eg. kg, t, etc.), with the decimal point in place. For example, if a scale is to weigh 500.0 kg in 0.5 kg increments, CAP is set to 500.0, and RES is set to 5.	Range: 000100 to 999999 Default: 003000
RES (Count-by Resolution) ⊗	Sets the resolution (or Count-by) of the display. The resolution is the number by which the indicator will count.	Options are: 1, 2, 5, 10, 20, 50 or 100 Default: 1
GRADS (Number of Graduations) ⊗ (K306 only)	Sets the number of graduations to be used for range 1 of the scale. If the GRADS multiplied by the RES is less than CAP, then dual range will be automatically enabled, otherwise GRADS will be ignored.	Range: 000100 to 030000 Default: 003000
UNITS (Weighed Units) ⊗	Sets the units for display and printing.	Options are: (g) grams, (kg) kilograms, (lb) pounds, (t) tonnes, () none (ie. other units). Default: kg (K307 Default: lb)
HI.RES (High Resolution x 10 mode) ⊗	Sets the instrument to display weight at 10 times resolution. This is intended for test purposes in trade applications but may be used for industrial weighing. This mode is indicated by the flashing of the units annunciator.	Options are: ON or OFF Default: OFF
CABLE (4-Wire or 6-Wire) ⊗	Sets the load cell input to operate in 4-wire (auto sense) or 6-wire mode.	Options are: 4 or 6 Default: 6

8.2.2. OPTION (Scale Options)

Items within this Group are used to configure the operating parameters of the scale.

USE (Scale Use) ⊗	This is where the basic use of the scale is set. This setting configures the instrument for Industrial, NSC, OIML, or NTEP operation. Refer to Industrial vs NSC, OIML and NTEP Mode page 28 for more information.	K304 & K306 options are: INDUST (Industrial), NSC, or OIML K307 options are: INDUST (Industrial), or NTEP Default: INDUST
FILTER (Reading Average)	The instrument can average a number of consecutive readings when calculating the displayed weight. This is used to dampen unwanted weight fluctuations caused by vibrations or dynamic forces. High settings will stabilise the display at the expense of rapid response to sudden weight changes.	NONE, 0.2, 0.5, 1.0, 2.0, 3.0, 4.0 (time in seconds) Default: 0.5 (seconds)
MOTION (Motion Detection) ⊗	Sets how much weight variation over a defined time period is allowed before the displayed weight is deemed to be unstable. This value is displayed as weight change (0.5 or 1.0 graduations) per second. When set to OFF, the Motion Detection is ignored and ZERO, TARE and PRINT actions are instantaneous.	OFF, 0.5-1.0, 1.0-1.0, 0.5-0.5, 1.0-0.5 (graduations per second) Default: 0.5-1.0 (0.5 graduations per second)
INIT.Z (Initial-Zero on Startup)	This function can be used to automatically ZERO the indicator during power-up. The amount of weight that can be zeroed is limited to +/- 10% of full scale.	ON or OFF Default: OFF
Z.TRAC (Zero Tracking Sensitivity) ⊗	Zero tracking allows the display to adjust for minor changes in the zero balance of the scale. When enabled, the instrument will track weight readings within the zero 'dead' band back to exactly zero at a maximum rate of 0.5 (SLOW) or 10 (FAST) graduations per second.	OFF, SLOW, FAST Default: OFF
Z.RANGE (Allowable Zero Operating Range) ⊗	This setting restricts the range over which the Zero functions can operate.	-2_2, -1_3, -20_20, FULL Default: -2_2 (-2% to 2%)
Z.BAND (Zero 'Dead' Band) ⊗	This is an adjustable margin either side of true zero that defines the zero 'dead' band. The zero 'dead' band is used by the automated functions to determine zero load (eg. a setting of 4 specifies that readings between -4.5 and 4.5 are considered to be zero). When the displayed weight reading is within this band the instrument displays the zero band annunciator. Refer to Status Annunciators page 21.	Settable over the full weight range. Always enter a number in multiples of display units. Refer to RES (Count-by Resolution) ⊗ page 33 for more information. Default: 0 (ie. -0.5 to 0.5 graduations)
R.ENTRY (Entry Means to Full Setup)	This setting can be used to restrict access to the full setup. The first entry to the full setup menu using the push button on the rear of the instrument causes all future access to the full setup to be restricted to the push button.	OFF, ON Default: OFF

8.2.3. CAL (Scale Calibration)

Items within this group perform various calibration routines. For detailed scale calibration procedures refer to Calibration page 42. Certain items in the Scale Build can affect the calibration of the scale. Always check that these sections are correctly configured to suit the current application before attempting to calibrate the scale.

ZERO (Zero Calibration) ⊗	Select to perform Zero Calibration. While the zeroing is in progress the display will show Z.in P. Refer to ZERO (Zero Calibration Routine) page 43.
SPAN (Span Calibration) ⊗	Select to perform Span Calibration. While the span calculation is in progress the display will show S.in P. Refer to SPAN (Span Calibration Routine) page 43.
ED.LIN (Edit Linearisation Points) ⊗ (K304 Only)	Select to view linearisation setup and start linearisation routines. While linearisation is in progress the display will show L.in P. Refer to ED.LIN (Edit Linearisation Points) page 45 for more information.
CLR.LIN (Clear Linearisation Points) ⊗ (K304 Only)	Select to view linearisation setup and select linearisation points to clear. Refer to CLR.LIN (Clear Linearisation) page 45 for more information.
DIR.ZER (Direct Zero Calibration) ⊗	Select to enter the mV/V value of the zero calibration directly. This feature is used to enable approximate calibrations to be performed in situations where a standard ZERO calibration is impractical (eg. calibration on a partially filled silo).
DIR.SPN (Direct Span Calibration) ⊗	Select to enter the mV/V value of the full scale capacity of the scale build. This feature enables the instrument to be calibrated based on the rated output capacity of the load cells rather than using test weights. The accuracy of this method is limited to the accuracy of the published load cell ratings.
G.INST (Installation Gravity) ⊗ (K306 Only)	Select to enter the gravitational acceleration of the location at which the scale is installed. Only necessary when using the Gravity Compensation feature. • Range 9.750 to 9.860 • Default: 9.810
G.FAC (Factory Gravity) ⊗ (K306 Only)	Select to enter the gravitational acceleration of the location at which the scale is calibrated. Only necessary when using the Gravity Compensation feature. • Range 9.750 to 9.860 • Default: 9.810
G.FIRST (First powerup prompt) ⊗ (K306 Only)	Select to set the indicator to prompt the user to enter the Installation Gravity on next powerup. Only necessary when using the Gravity Compensation feature. • Default: OFF
FAC.CAL (Restore Default Factory Calibration) ⊗	Select this choice to restore default factory calibration. This restores all calibration critical settings in the BUILD, OPTION and CAL menus back to factory defaults. The instrument will prompt with Cont. N. Press <EDT> to change to Cont. Y and <OK> to continue. If Cont. Y is chosen and then <OK> or <ITM> is pressed, the

	instrument will display DONE to indicate that the operation has been completed.
--	---

8.2.4. SPEC (Special Settings Menu)

Settings within this group control features including passcodes, key locking, key functions and display settings.

SAFE.PC (Safe Security Passcode for Digital Setup)	The SAFE.PC (Safe Passcode) allows partial access to Digital Setup (ie. only non calibration/trade critical settings can be changed). For the Safe Passcode to have any effect, the FULL.PC passcode must also be set. The default passcode setting is 000000 that allows free access. Any other number will enable the passcode functions and restrict access. Refer to Passcodes page 29 and Accessing Setup page 30 for more information.	Range 000000 to 999999 Default: 000000
FULL.PC (Full Security Passcode for Digital Setup)	The FULL.PC (Full Passcode) can be set to restrict access to Full Digital Setup. This passcode is used to prevent unauthorised or accidental tampering in the instrument setup. The default passcode setting is 000000 that allows free access. Any other number will enable the passcode functions and restrict access. Refer to Passcodes page 29 and Accessing Setup page 30 for more information.	Range 000000 to 999999 Default: 000000 It is important to note that when restricting Full access to Setup the passcode must not be forgotten. It is only possible to circumvent the passcode at the factory. Care must be taken when setting the Full Digital Setup Passcode to ensure that the instrument does not become permanently locked.
KEY.LOC (Front Panel Key Locking)	This item allows individual keys to be locked and unlocked. The display shows a dash (–) to indicate that a key is locked (inactive) or characters for each key that is active (ie. the characters P12345 display). The letter P represents the <POWER> key while the numbers 1234 and 5 represent the remaining operation keys. The operation keys are numbered from the left with the <ZERO> key being number 1. Note: When the <POWER> key is locked, the instrument cannot be turned off from the front keypad.	Default: P12345 - All keys are unlocked (active)

KEY.FN (Key Functions)	The function of the keypad <FUNCTION> key can be selected here. Refer to Special Functions page 53 for details of the available key functions.	NONE, TEST, COUNT, UNITS, HOLD, PEAK.H, LIVE.WT, SHOW.T, HI.RES, A.TARE, CHECK.W Default: NONE
AUT.OFF (Auto Power Off / Battery Operation)	The instrument can be set up to automatically power down after a period of no activity. Weight motion, network communications or any press of the keyboard is enough to keep the instrument powered on. When operating on batteries the instrument will turn off after 30 minutes of inactivity even if set to NEVER.	NEVER: Never power off automatically (Battery: powers down after 30 minutes) 1, 5, 10 (time in minutes) Default: NEVER
B.LIGHT (Backlight Operation)	Sets the operation of the backlight. When operating the backlight with batteries the brightness is lowered automatically to conserve power and the backlight will automatically turn off after 10 seconds of inactivity. To turn on again, press the <POWER> key.	OFF: Backlight is off ON: Backlight is on when motion, network communications, or any keypress is detected. FORCED: Backlight is permanently on. Default: ON
REM.FN (Remote Function)	This item allows the indicator to be triggered from a remote input (see section 3.9.2 Remote Input). The remote input can be set to have no function (ie. NONE) or it can be set to mimic one of the front five panel key functions (ie. where KEY1=ZERO, KEY2=TARE, KEY3=GROSS/NET, KEY4=PRINT and KEY5=FUNCTION). The remote input can also be set to BLANK where, when the remote input is pressed and held, the indicator displays dashes (ie. - - - - -) and the front five key functions are disabled. When the remote input is released the indicator display and front key functions return to normal. For the REM.FN to have any effect, the SERIAL:TYPE item must be set to AUTO. Refer to TYPE (Serial Output Type) below for more information.	NONE: No function. KEY1 to KEY 5: Mimic one of the front five function keys BLANK: Display dashes (ie. - - - - -) and disable front key functions. Default: NONE

REM.CHR (Remote Input Transmit Idle Character)	The remote input transmit idle character specifies the character to be transmitted whilst the serial transmitter is idle, regardless of the state of the DTR line. This character is only transmitted when a remote function (SPEC:REM.FN) is enabled, and serial port type (SERIAL:TYPE) is set to PRINT or AUTO.PR. This function allows the remote input to function even when a printer is connected. This character must be chosen so it is ignored by the printer. Typically the ENQ (ASCII 05) character is suitable.	Range 000 to 255 Default: 005
BAT.VLT (Battery Voltage)	The indicator can be setup for a variety of different batteries. The low battery annunciator will display when the battery voltage drops below 1V per cell. For example, a 6 cell, 7.2V battery pack, has a low battery level of 6V. The indicator will assume it is on battery power when its input voltage is less than twice the low battery level for the selected battery voltage. In the PWR mode the indicator will always assume it has external power. Correct function of the low battery warning is dependant on correct setting of the battery voltage.	PWR: (External power – battery not used) 9.6, 12, 24 (Battery Voltage) Default: PWR
W.D.LOCK (Wash Down Key Lock)	This item requires a sequence of keys to be pressed when the instrument is turned on. If an incorrect key is pressed or the key is not pressed within 5 seconds then the instrument will turn back off.	OFF: Key lock is off ON: Key lock is on Default: OFF

8.2.5. SERIAL (Serial Communications Options)

Settings within this Group determine the serial and printing outputs. Refer to Serial Outputs page 47 for more information on Serial configuration.

TYPE (Serial Output Type)	Sets the function of the first serial output. The port can be disabled or set to run as an automatic output or a network device.	NET: Network Communications. AUTO: Enables 10 Hz automatic transmission using the format selected below (SERIAL:FORMAT). SINGLE: Enables transmission on pressing the <PRINT> key using the format selected below (SERIAL:FORMAT). The RS232 is set to high impedance at the completion of the transmission. A long press of the <PRINT> key has no effect. PRINT: Enables printer driving. AUTO.PR: A single printout occurs when the weight is stable after being at zero, and higher than the greater of 20 divisions or zero band. Default: NET
FORMAT (Serial Output Format)	The Format determines the transmission format for AUTO and SINGLE serial types.	FMT_1: Format 1. FMT_2: Format 2. MASTER: Send contents of LCD display to a remote display. CUSTOM: Send a custom print string to a remote display.
BAUD (Serial Baud Rate)	The baud rate determines the serial data transmission speed.	Options are: 2400, 4800, 9600 Default: 9600
BITS (Serial Format Options)	The Bits options allow the data transmission bit pattern and interface to be changed. The display will show the current setting in the form n81- where each character has a meaning as shown below.	N or O or E: Parity bit: (N) None, (O) Odd, (E) Even 8, 7: Number of data bits 1, 2: Number of stop bits , D: DTR handshake disabled or enabled Default: n81-. (For most applications the default setting is applicable.)
ADDRES (Instrument Address)	Use this option to set the instrument address when operating with network communications.	Range 01 to 31 Default: 31
RST.CON (Reset Printed Consecutive Number) ⊗	Use this option to reset the printed consecutive number back to 1. The instrument will prompt with Cont. N. Press <EDT> to change to Cont. Y and <OK> to continue. When Cont. Y has been chosen the instrument will display DONE to indicate that the operation has been completed.	

8.2.6. CHECK.W (Check Weighing Settings)

Settings within this group configure the check weighing system. Refer to Check Weighing page 52 for a detailed explanation of check weighing.

ENABLE	Enable check weighing.	OFF: Check weighing is disabled (turned off). ON: Check weighing is enabled (turned on). Default: OFF
SRC (Weight Source for check weighing)	The weight source determines the weight reading that is used for check weighing.	GROSS: Use gross weight readings always. DISP: Use the displayed weight (gross or net). NET: Use net weight readings always. Default: GROSS
OVER (Target for Over)	This is the target value for over. This target provides the threshold value when check weighing is enabled.	Range: -99999 to 999999 Default: 000000
UNDER (Target for Under)	This is the target value for under. This target provides the threshold value when check weighing is enabled.	Range: -99999 to 999999 Default: 000000

8.2.7. CLOCK (Clock Settings)

Items within this group set date and time related functions.

FORMAT (Date Format)	This sets the date format.	dd.mm.yy mm.dd.yy Default: dd.mm.yy (K307 Default: mm.dd.yy)
YEAR (Set Year)		Range: 2000 to 2099
MONTH (Set Month)		Range: 01 to 12
DAY (Set Day)		Range: 01 to 31
HOURL (Set Hour)		Range: 00 to 23 (24-hour format)
MINUTE (Set Minute)		Range: 00 to 59

8.2.8. TEST (Special Test Functions)

Items within this Group allow access to the testing routines for the instrument. With these routines the scale base output can be monitored and the inputs and outputs can be tested.

SCALE (Scale Base Test Display)	Verifies the correct load cell capacity and/or load cell wiring is used. It sets up the instrument as a simple test meter to measure the load cell signal output. The display reads in millivolts-per-volt, factory calibrated to 0.1% worst case. When accessing this item, initially there should be no weight on the scale. In NSC, OIML or NTEP modes, this display is only active for five seconds before returning to the menu.
FRC.OUT (Force Outputs)	Forces over, under and pass output drivers in turn. All outputs turn OFF when leaving this step. The <EDT> key will advance through each output (ie. ON.1 ON.2 and ON.3). Pressing <OK> will turn all outputs off and exit the test.
O.LOAD (Overload Count)	Displays a count of the number of times that the A/D conversion has been out of range since the count was last reset. This value is read only and cannot be edited.

CLR.OLD (Clear Overload)	Clears the A/D conversion overload counter. The instrument will prompt with Cont. N. Press <EDT> to change to Cont. Y and <OK> to continue. When Cont. Y has been chosen the instrument will display DONE to indicate that the operation has been completed.
-----------------------------	--

8.2.9. FACTRY (Factory Adjustment Menu)

DEFLT (Restore Factory Settings Except for Calibration and Build)	Restores all settings in the digital setup, which are not calibration critical back to the original new settings installed at the factory. The main use of this routine is to completely reset an instrument that is being installed on a different scale. The instrument will prompt with Cont. N. Press <EDT> to change to Cont. Y and <OK> to continue. When Cont. Y has been chosen the instrument will display DONE to indicate that the operation has been completed. Restoring the factory options does not affect the calibration. To reset the calibration to factory condition CAL:FAC.CAL must be used. Refer to FAC.CAL (Restore Default Factory Calibration) ⊗ page 35. This menu item is only available when in Full Digital Setup mode.
--	---

8.2.10. – End – (Leaving Setup)

Refer to Exiting Full or Safe Setup page 31.

9. Calibration

The calibration of the indicator is fully digital. The calibration results are stored in permanent memory for use each time the instrument is powered up.

Note: Some of the digital setup steps can affect calibration. The BUILD and OPTION settings MUST be configured before calibration is attempted.

To perform a calibration, when in Full Setup select the **CAL** Group using the **<GRP>** key.

The calibration programme will automatically prevent the instrument from being calibrated into an application outside of its specification. If an attempt is made to calibrate outside of the permitted range, an error message will display and the calibration will be abandoned. Refer to Error Messages page 61.

The instrument has a wide-range A/D converter. The industrial calibration range of the instrument extends well beyond the Trade approved range.

Note: It should not be assumed that just because the instrument has successfully calibrated a scale, that the scale is correct for trade use. Always check the scale build against the approval specification.

9.1. Performing a Digital Calibration with Test Weights




Figure 16: Chart - Zero and Span Points to Interpolate Weight from Load Cell

The Zero setting (CAL:ZERO) specifies a gross zero point for the scale. The Span setting (CAL:SPAN) specifies a second point (**preferably close to full scale**) used to convert the A/D readings into weighing units (eg. kg). Select either of the Zero (CAL:ZERO) or Span (CAL:SPAN) calibration items. It is important that an initial Zero calibration is performed before any SPAN calibrations. The chart shown here demonstrates how the zero and span points are used to interpolate a weight reading from the load cell reading.

Note: Calibration points (Zero, Span and Linearisation) must be spaced by at least 2% of Full scale from each other.

9.1.1. ZERO (Zero Calibration Routine)

Press the <SEL> key to start. The display will show the current weight. Remove all weight from the scale structure.
Press <SEL> , <EDT> or <OK> to execute a Zero Calibration. The display will show Z.in.P to indicate that zeroing is in progress. When the process is complete the display will return to weight to allow the zero to be checked.
Press the <ITM> key to leave the Zeroing routine or press <SEL> , <EDT> or <OK> to repeat the operation.

9.1.2. SPAN (Span Calibration Routine)

Press <SEL> or <OK> to start. The display will show the current weight.
Use <EDT> to select whether the linearisation points need clearing CLr.L y , or not CLr.L n . Press <OK> to continue.
Add the calibration test mass to the scale. The minimum acceptable span calibration weight is 2% of the scale range. A weight this small may limit calibration accuracy. The closer the test weight is to full scale the better the accuracy.
Press <SEL> or <OK> to show the calibration weight value. Change this to the correct calibration weight using the <SEL> and <EDT> keys.
Press <ITM> or <OK> to trigger the Span Calibration routine. The display will show S.in P to indicate that spanning is in progress. When the process is complete the display will return to weight to allow the new weight reading to be checked.
When the Span Calibration is complete, press the <ITM> key to leave the Spanning routine or press <SEL> , <EDT> or <OK> to re-edit the calibration weight and repeat the operation.

9.2. Performing a Calibration with Direct mV/V Entry

In applications where test weights are not easily available, it is possible to calibrate the instrument directly by entering the mV/V signal strength at Zero and full scale Span. The Direct Zero setting (CAL:DIR.ZER) specifies a gross zero point for the scale. The Direct Span setting (CAL:DIR.SPN) specifies the mV/V signal strength corresponding to an applied mass equal to the full scale reading. This calibration technique is not compatible with linearisation. Clearly the accuracy of this type of calibration is limited to the accuracy of the direct mV/V data.

9.2.1. DIR.ZER (Direct Zero Calibration Entry)

Press the <OK> key to start. The display will show the current weight.
Press the <OK> key to enter the Direct Zero setting. Change the mV/V setting to the correct value for Zero using the <SEL> and <EDT> keys.
Press the <OK> key to store the new zero calibration. When the process is complete the display will return to weight to allow the new weight reading to be checked.
Press the <ITM> key to leave the Direct Zero routine or <OK> to repeat the operation.

9.2.2. DIR.SPN (Direct Span Calibration Entry)

Press the <OK> key to start. The display will show the current weight.
Press the <OK> key to enter the Direct Span setting. Change the mV/V setting to the correct value for the full scale signal strength, using the <SEL> and <EDT> keys.
Press the <OK> key to store the new span calibration. When the process is complete the display will return to weight to allow the new weight reading to be checked.
Press the <ITM> key to leave the Direct Span routine or <OK> to repeat the operation.

9.3. Using Linearisation (K304 only)

This section provides instructions on the use of the linearisation. Linearisation is used to approximate the weight output to a non-linear scale. The chart below shows a non-linear characteristic for the load cell output. From the chart, it can be seen that the trace with no linearisation applied is a poor approximation to the real characteristic. By applying one or more linearisation points, more accurate weight readings can be achieved.




Figure 17: Chart - Non-Linear Characteristic for Load Cell Output

To perform a linearisation, a calibration of the zero and full scale span points must have been performed. Both the zero and full scale calibration points are used in the linearisation of the scale base. These two points are assumed to be accurately set and thus have no linearisation error.

A maximum of ten linearisation points can be set independently between zero and full scale. Unused or unwanted points may also be cleared. The maximum correction that can be applied using a linearisation point is $\pm 2\%$.

9.3.1. ED.LIN (Edit Linearisation Points) (K304 only)

Press the <SEL> key to step through the list of points. Each point is shown as Ln.ppp where n is the point number (1 to 10), and ppp is the approximate percentage of full scale where the linearisation is applied. For example, L1.050 indicates that linearisation point one is active and was entered at about 50% of full scale. Unused linearisation points are shown with a row of dashes (eg. L2. - -).
Press <OK> to change the linearisation point selected or press <ITM> to exit without making any changes.
After pressing <OK> , the current weight reading is displayed. Add the calibration test mass to the scale. The closer the test mass is to the point of maximum error in linearity the more effective will be the correction. Press <OK> to enter a corrected weight value for this point or <ITM> to exit without making changes.
Use the <SEL> and <EDT> keys to enter the correct value of the calibration weight being used.
Press the <OK> key to trigger the Linearisation routine. The display will show L.in P to show that linearisation is in progress. When the process is complete the display will show the weight to allow the new weight reading to be checked before returning to the menus. Press <ITM> to leave the routine or <OK> to repeat the operation.

9.3.2. CLR.LIN (Clear Linearisation) (K304 only)

Press the <SEL> key to step through the list of points. Each point is shown as Ln.ppp where n is the point number (1 to 10), and ppp is the approximate percentage of full scale where the linearisation is applied. For example, L1.050 designates that linearisation point one is active and was entered at about 50% of full scale. Unused linearisation points are shown with a row of dashes (eg. L2. - - -).
Press <OK> to choose the linearisation point to clear. The indicator will prompt to continue with CONT. N . Press <EDT> to switch between Cont. N (No) and Cont. Y (Yes). The <OK> key is used to accept your choice. When Cont. Y has been chosen the cleared linearisation point then displays (eg. L1. - - -).
Press <ITM> to return to CLR.LIN .

Note: All linearisation points are cleared by restoring the default calibration of the instrument. The zero and span settings are also cleared by this process.

9.4. Using Gravity Compensation (K306 only)

To make use of this feature, the gravitational acceleration of the factory (G.FAC) and the installation location (G.INST) must be known. The indicator uses these 2 settings to compensate for the change in gravitational acceleration between locations.

The following procedure can be used when a scale is to be calibrated at one location and then installed at a different location.

1. Set the factory gravitational acceleration (G.FAC) to that of the location the scale is being calibrated at.
2. Perform a Zero and Span calibration. Note: When a Zero or Span calibration is performed the G.INST setting is reset to equal G.FAC.
3. Set the G.FIRST setting to ON. This enables the user prompt.

The scale can then be sent to the installation location. When the indicator is powered up the user will be prompted to enter the gravitational acceleration of their location (G.INST). At this prompt the user can enter this setting one time only without affecting the calibration counter. Once a valid setting has been entered, the user will not be prompted again.

The G.INST setting can be edited directly in the calibration menu however this will result in the calibration counter being incremented.

10. Serial Outputs

The instrument can support the optional temporary opto-LINK connection, activation is discussed on page 15. In addition, there is a single bi-directional RS-232 output. This provides a number of serial output types allowing communications with external devices such as printers, computers, PLCs or remote displays. For wiring connections and pin outs, refer to Auxiliary Connection page 10.

The available serial types include:

- Network Communications
- Automatic Output
- Single Output
- Printing
- Automatic Printing

10.1. Network Communications

10.1.1. COMM Protocol

The **COMM** network communications feature is normally used to control indicators remotely from a central computer, or PLC. A **COMM** command and response might be:

```
20110150:<CR><LF>
```

```
9F110150:07/01/2030 17:29<CR><LF>
```

10.1.2. Ring Network Enhancement

Instruments can be installed in a Ring Network. This also requires the central computer to send additional framing characters, 'Echo-On' (= <DC2> = ASCII 12_H) and 'Echo-Off' (= <DC4> = ASCII 14_H) around each command. A Ring Network enhanced **COMM** command and response might be:

```
<DC2>20110150:<CR><LF>  
<DC4>
```

```
<DC2>20110150:<CR><LF>  
9F110150:07/01/2030 17:29<CR><LF>  
9E110150:07/01/2030 17:30<CR><LF>  
<DC4>
```

For more information on the **COMM** Protocol and the Ring Network Enhancement, please refer to the Communications Manual.

10.2. Automatic and Single Output

Automatic - The automatic output is normally used to drive remote displays, a dedicated computer, or PLC communications.

Single - The single output produces a single output with the formats selected. It is used to drive remote displays, a dedicated computer, or PLC communications.

The Automatic Weight Output and Single Output types have several formats available including:

- Format 1
- Format 2

- Master / Slave
- Custom

All serial output options are enabled and configured using the serial communications options in the digital setup procedure. Refer to SERIAL (Serial Communications Options) page 39.

The instrument computer communications can range from simple automatic streamed output, through to a command-response system. In addition to the opto-LINK, the instrument can be programmed and calibrated via the RS-232 serial port. The calibration counter is incremented when the calibration related steps are accessed via RS-232, the serial port or the opto-LINK. This means that calibration via the serial port or opto-LINK cannot be carried out without affecting the certification of a trade installation.

Auto Weight Format String

The weight format string may be set to the following formats:

Format	Description
FMT_1	<STX> <SIGN> <WEIGHT(7)> <STATUS> <ETX>
FMT_2	<STX> <SIGN> <WEIGHT(7)> <S1> <S2> <S3> <S4> <UNITS(3)> <ETX>

Where

- **STX**: Start of transmission character (ASCII 02).
- **ETX**: End of transmission character (ASCII 03).
- **SIGN**: The sign of the weight reading (space for positive, dash (-) for negative).
- **WEIGHT(7)**: A seven character string containing the current weight including the decimal point. If there is no decimal point, then the first character is a space. Leading zero blanking applies.
- **STATUS**: Provides information on the weight reading. The characters G/N/U/O/M/E represent Gross / Net / Underload / Overload / Motion / Error, respectively.
- **UNITS(3)**: A three character string, the first character being a space, followed by the actual units (eg. ^kg or ^t). If the weight reading is not stable, the unit string is sent as ^^^.
- **S1**: Displays G/N/U/O/E representing Gross / Net / Underload / Overload / Error, respectively.
- **S2**: Displays M/^ representing Motion / Stable, respectively.
- **S3**: Displays Z/^ representing centre of Zero / Non-Zero, respectively.
- **S4**: Displays - representing single range.

Master Serial Output

In **Master** mode, the instrument sends out the entire contents of the LCD every 100msec. This is essentially the same as AUTO output but the format of the output string is designed to allow a remote display to exactly copy the contents of the LCD including all of the annunciators and user prompts, etc.

10.3. Printing

When the instrument has print or automatic print enabled selection between the standard printing format and the programmable printing format is automatic. If there is programmable printing data available then it will be used for the printing. If there is

no programmable printing data available then the standard printing format will be used.

10.3.1. Standard Printing

The instrument has a single fixed printing format that is as follows:

```
000048 06/05/2003 15:10
          121.4 kg G
          43.5 kg N
          77.9 kg T
```

The first line contains a six digit sequential number that is automatically incremented with each printing, up to a maximum of 999999. The first line also contains the current date and time, printed in the selected format.

The second line shows the displayed reading, units and **G** for Gross or **N** for Net.

The third line shows the Net reading when the Gross reading is displayed on the second line, and the Gross reading when the Net reading is displayed on the second line.

The fourth line shows the Tare reading when the Gross reading is displayed on the second line, and the Gross reading, units and **G** for Gross or **N** for Net.

If counting is active, the printout has a fifth line for the counting information (**p** for pieces) as follows:

```
164 p
```

Whenever a new sample is taken when counting, the instrument prints the sample as in the following format:

```
SAMPLE: 100 p = 50.0 kg
```

In addition to the printout, the instrument adds the weight and pieces printed to the internal weight and count totals. A long press of the **<PRINT>** key will print and clear these totals. The six digit sequential number is not cleared. Note: For K307, separate GROSS and NET totals are recorded, and totalising will not occur until Accumulation mode is enabled. Refer to Accumulation Mode page 27 for details.

The following is a sample of a total ticket:

```
000049 06/05/2003 15:20
          90.6 kg G
          0.0 kg N
          0.0 kg T
000050 06/05/2003 15:21
          154.9 kg G
          0.0 kg N
          0.0 kg T
000051 06/05/2003 15:21
          50.4 kg G
          0.0 kg N
          0.0 kg T
000052 06/05/2003 15:21
          71.0 kg G
          0.0 kg N
          0.0 kg T
000053 06/05/2003 15:21
          13.3 kg G
          0.0 kg N
          0.0 kg T
ITEMS: 5
TOTAL: 380.2 kg
```

If counting is active each of the individual printouts would have a third line as discussed above and the **TOTAL** would have an additional QTY line as follows:

000054	06/05/2003	15:22	
	13.3	kg	G
	27	p	
000055	06/05/2003	15:23	
	79.3	kg	G
	159	p	
000056	06/05/2003	15:23	
	117.0	kg	G
	234	p	
ITEMS:	3		
TOTAL:	209.6	kg	
QTY:	420	p	

10.3.2. Programmable Printing

Two user determined print strings with tokens can be loaded into an instrument using the viewer. Once the instrument is connected and has a full session started select the instrument menu at the top of the viewer and select custom print format. Here you can edit the two custom print strings, any hex values (such as tokens) should be preceded with a "\". All hex values less than 7F_H will be interpreted as ASCII characters. Alternatively you can use the protocols and techniques described in the "Communications Manual" to enter custom strings.

The following tokens are available:

Token Name	Hex Value	Description
Gross Weight	CF _H	Current gross weight
Net Weight	DO _H	Current net weight
Tare Weight	D8 _H	Current tare weight
Display Weight	D9 _H	Current display weight
Count	F0 _H	Current count (if counting is turned on)
ID	DA _H	Current print ID
Time	C0 _H	Current time
Date	BF _H	Current date
Total Weight	DB _H	Total of printed Display Weight since last summary print (long press).
Total Count	DD _H	Total number of pieces in Total Weight (if counting turned on)
Items	DC _H	Number of items printed since last summary print.
Standard Print (short press)	7F _H	Standard print
Standard Print (long press)	8F _H	Standard summary
Streaming Register Literal	E8 _H	Literal value of streaming register(s)
Streaming Register Raw	E9 _H	Raw value of streaming register(s)

For example the following data loaded :

```
\D9 at \C0 on \BF\0D\0A
```

Would produce the printout below:

```
523 kg G at 09:18 on 10/08/2006[CR][LF]
```

The menu selection FACTRY:DEFLT is used to clear the programmed printing and revert to the standard printing format.

A short press of the **<PRINT>** key will print the programmed print string up to 80 characters including tokens.

A long press of the **<PRINT>** key will print the programmed summary print string up to 20 characters including tokens.

11. Check Weighing

The instrument is capable of performing as a check weigher. The status of the check weighing is displayed on the LCD and the three LEDs on the front of the indicator. Each value is associated with a physical output driver but it may also be simply used as an indicator.

Refer to CHECK.W (Check Weighing Settings) page 40 for details on settings.

11.1. Output Connection

Refer to Auxiliary Connection page 10 for the method of connection of the external output drivers.

11.2. Check Weighing Operation

The CHECK.W:SRC setting allows the gross weight or displayed weight to be chosen as the source for the setpoint operation. This allows the over and under limits to be linked to gross weights always or alternatively to be linked to the current displayed weights.

The CHECK.W:OVER/UNDER values set the values for the over and under limits.



Annunciator is displayed in the lower section of the display when the reading is above the over value.



Annunciator is displayed in the lower section of the display when the reading is below the under value.



Annunciator is displayed in the lower section of the display when the reading is between the over and under values.

12. Special Functions

12.1. Introduction



The instrument has a special function key on the front panel. This function of this key can be configured to any of the key functions detailed below. Refer to KEY.FN (Key Functions) page 37 to configure the function key.

When leaving the factory, the **<FUNCTION>** key is blank and has no primary function pre-programmed. Each primary function has an associated overlay sticker (supplied) that should be applied to the function key to label the function. Ensure the keypad is clean and dry before affixing the sticker. Refer to Cleaning page 7 for more information.

12.2. Key Functions

12.2.1. NONE

When set to **NONE** the special function key is not used during normal operation. This is the default setting.

12.2.2. TEST

Press the **<TEST>** key to clear the display then show all segments of the display then clear the display again before returning to normal operation.

12.2.3. COUNT

Use this key to perform pieces counting. Press the **<COUNT>** key to switch between weight display and counts display. The instrument annunciator shows **p** for pieces.

To record a new sample do the following:

Tare off any containers.
Place the sample on the scale
Press and hold the <COUNT> key for two seconds. The default number of items in the sample will be displayed.
Use the <SEL> and <EDT> keys to alter the number of items.
Press <OK> and the current sample will be stored against the entered items.
If printing is enabled the sample quantity and weight will be printed.

12.2.4. UNITS

Use the **<UNITS>** key to switch the displayed reading between **lb** and **kg**. This will affect the displayed and printed weight but will not affect any data entry. The following is a sample of a printout displaying kg and lb.

```
000009 06/05/2003 16:31
          2.8 kg G
000010 06/05/2003 16:31
          6.1 lb G
```

12.2.5. HOLD and PEAK HOLD

The **<HOLD>** key implements a manual **Hold** function. The **<PEAK>** key implements a **Peak Hold** function where the largest absolute weight, either positive or negative is stored in the peak value (eg. -30 is larger than 25). The **Hold** annunciator is active when the display is showing the held weight. Refer to Status Annunciators page 21.

To perform the **Hold** function, do the following:

- | |
|--|
| Press the manual <HOLD> key once to hold the current displayed weight. |
| Press the manual <HOLD> key again to return the display to normal weighing. |

To perform the **Peak Hold** function do the following:

- | |
|---|
| Press the <PEAK> hold key once to show the absolute peak weight reading. |
| Press the <PEAK> hold key again to return the display to normal weighing. |
| A long press of the <PEAK> hold key clears the peak value back to 0 (zero). |

All printouts that print the displayed weight will use the held weight reading if it is currently being displayed. K307 will not print while a weight is held.

12.2.6. LIVE.WT

The **<LIVE.WT>** key is used to enable live weight averaging. With this feature, it is possible to determine the weight of a continually moving mass (eg. livestock).

- | |
|---|
| Press and hold the <LIVE WT> key to switch between normal weighing and live weight mode. The display will briefly show NORMAL or LIVE.WT . |
|---|

During normal weighing, this key operates exactly like a manual **<HOLD>** key.

In Live-Weight mode the following sequence is followed:

- | |
|--|
| While the net weight is within the zero 'dead' band, the instrument shows the current weight. |
| Press the <TARE> or <ZERO> key to clear any residual weight and return the scale to the zero state. |
| Place the mass to be weighed on the scale. |
| Once the weight moves outside the zero 'dead' band the instrument begins to calculate a long term average that compensates for any movement in the mass. The instrument flashes the Hold annunciator and shows the current average value. |
| The Hold annunciator is steady when the final sample weight is shown on the display. |
| Press the <LIVE WT> key to force the sample to be re-calculated. |
| Once the weight is returned to the zero 'dead' band, the cycle can be repeated. |

12.2.7. SHOW.T

The **SHOW.T** item stands for **Show Total**. The function key will be labelled **<TOTAL>**.

The **PRINT** key is used not only to print the current weight but also to add that weight to the current total.

When the <TOTAL> key is pressed the indicator displays count followed by the number of items in the total.
--

After this, TOTAL is displayed followed by the current total weight.

If the total weight is too large to display in six digits, the weight is shown in two sections labelled with the upper six digits displayed before the lower six digits.

A long press of the **<PRINT>** key causes the total accumulated weight to be printed and then cleared. The SERIAL:TYPE option must be set to PRINT to activate this function.

12.2.8. HI.RES

The **<HI.RES>** key is used to switch the display between normal and a high resolution (x10) display of the weight. The high resolution display is identified by flashing units.

12.2.9. A.TARE

The **<A.TARE>** key is used to enable the automatic tare feature. This feature when enabled will cause the indicator to be tared whenever the weight is motionless above the autotare threshold and has been below the autotare threshold since the last autotare. The tare weight is reset to zero when the autotare feature is active and the gross weight is motionless within the zero “dead” band.

Press the <A.TARE> key to switch between normal weighing and automatic tare mode. An ► annunciator will appear in the middle of the right hand side of the display to indicate that the automatic tare mode is active.

Press and hold the <A.TARE> key to set the threshold above which the automatic tare occurs.
--

Press the <OK> key to enter the automatic tare threshold. Change the threshold to the required value using the <SEL> and <EDT> keys.

Press the <OK> key to store the new automatic tare threshold. When the process is complete the display will return to weight.
--

In automatic tare mode the following sequence is typically followed:

The threshold is set to below the minimum box weight.

After the instrument has been zeroed, the instrument shows the current gross weight.
--

While the gross weight is below the threshold, the instrument shows the current gross weight.

A box is placed on the scale. When the displayed gross weight is stable above the threshold weight. The instrument will automatically tare and the net weight of zero will be displayed.
--

The box is filled with the instrument displaying the net weight.
--

The filled box is removed from the scale.

When the gross weight is stable within the zero 'dead' band the instrument will automatically zero and the gross weight of zero will be displayed.
--

The next box can be placed on the scale and the process repeated.

12.2.10. CHECK.W

The **<CHECK.W>** key is used to gain access to the check weighing threshold values. A short press of the key displays the threshold values while a long press enables editing of the threshold values.

A short press the < CHECK.W > key will display “ Over ”, followed by the over target, followed by “ Under ”, followed by the under target
--

Press and hold the < CHECK.W > key to edit the target threshold associated with over. The “ Over ” annunciator appears briefly on the display before editing mode is entered to indicate that the over threshold is being edited.

Press the <OK> key to enter the over threshold. Change the threshold to the required value using the <SEL> and <EDT> keys.

Press the <OK> key to store the new over threshold. When the process is complete the display will move on to editing the under threshold.
--







The “ Under ” annunciator appears briefly on the display before editing mode is entered to indicate that the under threshold is being edited.
--

Press the <OK> key to enter the under threshold. Change the threshold to the required value using the <SEL> and <EDT> keys.
--


Press the <OK> key to store the new under threshold. When the process is complete the indicator will revert to the condition it held prior to the initial pressing of the < CHECK.W > key.
--

13. Appendix


13.1. Dimensions

Weight Indicator		Dimensions in mm (1 inch = 25.4 mm)	
3D View		Front View	
			
Side View		Bottom View	
			
Weight Indicator (Wall Mount)		Dimensions in mm (1 inch = 25.4 mm)	
3D View		Stand Assembly	
			

13.2. Sealing Details



Attachment of Lead Seal through optional Captive Security Screws. Please note that security screws are available as an option and that they are less corrosion resistant than the standard Captive Screws.



Back View showing cable locations.

13.3. Setup Menu Quick Reference

Note: ⊗ Available only in Full Setup. Changing this setting **will increment** the Calibration Counter.

1 Available only in Full Setup. Changing this setting **will not increment** the Calibration Counter.

Group (GRP)	Item (ITM)	Page	⊗
BUILD	DP (Decimal Point Position) ⊗	33	⊗
	CAP (Maximum Capacity) ⊗	33	⊗
	RES (Count-by Resolution) ⊗	33	⊗
	GRADS (Number of Graduations) ⊗	33	⊗
	UNITS (Weighed Units) ⊗	33	⊗
	HI.RES (High Resolution x 10 mode) ⊗	33	⊗
	CABLE (4-Wire or 6-Wire) ⊗	33	⊗
OPTION	USE (Scale Use) ⊗	34	⊗
	FILTER (Reading Average)	34	
	MOTION (Motion Detection) ⊗	34	⊗
	INIT.Z (Initial-Zero on Startup)	34	
	Z.TRAC (Zero Tracking Sensitivity) ⊗	34	⊗
	Z.RANGE (Allowable Zero Operating Range) ⊗	34	⊗
	Z.BAND (Zero 'Dead' Band) ⊗	34	
	R.ENTRY (Entry Means to Full Setup)	34	⊗
CAL	ZERO (Zero Calibration) ⊗	35	⊗
	SPAN (Span Calibration) ⊗	35	⊗
	ED.LIN (Edit Linearisation Points) ⊗	35	⊗
	CLR.LIN (Clear Linearisation Points) ⊗	35	⊗
	DIR.ZER (Direct Zero Calibration) ⊗	35	⊗
	DIR.SPN (Direct Span Calibration) ⊗	35	⊗
	G.INST (Installation Gravity) (K306 Only)	35	⊗
	G.FAC (Factory Gravity) (K306 Only)	35	⊗
	G.FIRST (Prompt on first powerup) (K306 Only)	35	⊗
	FAC.CAL (Restore Default Factory Calibration) ⊗	35	⊗

SPEC	SAFE.PC (Safe Security Passcode for Digital Setup)	36	
	FULL.PC (Full Security Passcode for Digital Setup)	36	1
	KEY.LOC (Front Panel Key Locking)	36	
	KEY.FN (Key Functions)	37	
	AUT.OFF (Auto Power Off / Battery Operation)	37	
	B.LIGHT (Backlight Operation)	37	
	REM.FN (Remote Function)	37	
	REM.CHR (Remote Input Transmit Idle Character)	38	
	BAT.VLT (Battery Voltage)	37	
	W.D.LOCK (Wash Down Key Lock)	37	
SERIAL	TYPE (Serial Output Type)	39	
	FORMAT (Serial Output Format)	39	
	BAUD (Serial Baud Rate)	39	
	BITS (Serial Format Options)	39	
	ADDRES (Instrument Address)	39	
	RST.CON (Reset Printed Consecutive Number) ⊗	39	⊗
CHECK.W	ENABLE	40	
	SRC (Weight Source for check weighing)	40	
	OVER (Target for Over)	40	
	UNDER (Target for Under)	40	
CLOCK	FORMAT (Date Format)	40	
	YEAR (Set Year)	40	
	MONTH (Set Month)	40	
	DAY (Set Day)	40	
	HOUR (Set Hour)	40	
	MINUTE (Set Minute)	40	
TEST	SCALE (Scale Base Test Display)	40	
	FRC.OUT (Force Outputs)	40	
	O.LOAD (Overload Count)	40	
	CLR.OLD (Clear Overload)	41	
FACTRY	DEFLT (Restore Factory Settings Except for Calibration and Build)	41	1
- END -	Save settings and return to normal weighing mode. Refer to Exiting Full or Safe Setup	31	

13.4. Error Messages

A number of error messages may be displayed to warn of operation outside of the acceptable limits. These messages are described below. Short messages (XXXXX) will appear as a single message on the display. Longer messages (XXXXX) (YYYYY) will appear on the display in two parts, first the (XXXXX) part, then the (YYYYY) part.

13.4.1. Weighing Errors

These messages show status messages or errors that may occur during normal weighing operation.

Error	Description	Resolution
(U - - - -)	The weight is below the minimum allowable weight reading.	Increase the weight or decrease the minimum allowable weight reading.
(O - - - -)	The weight is above the maximum allowable weight reading. Warning - overloading may damage mechanical scale elements.	Check the condition of load cell connections. Check for damaged load cell.
(ZERO) (ERROR)	The weight reading is beyond the limit set for Zero operation. The operation of the <ZERO> key is limited in the setup during installation. The indicator cannot be Zeroed at this weight.	Increase the Zero Range (Z.RANGE) or use the <TARE> key instead.
(STABLE) (ERROR)	Scale motion has prevented a <ZERO> or <TARE> operation from occurring on command.	Try the operation again once the scale is stable.

13.4.2. Setup and Calibration Errors

These messages show status messages or errors that may occur during the instrument setup and calibration.

Error	Description	Resolution
(ENTRY) (DENIED)	The instrument may be in Safe Setup and an item that needs Full Setup has been selected for editing.	Access Full Setup to edit the item.
	When accessing setup, more than three attempts have been made with the incorrect passcode. Refer to Setup Lock-Out page 29 for more information.	Turn the instrument off. When the instrument is turned back on, enter the correct passcode to access setup.
(LIN.PT) (LO)	An attempt has been made to place a linearisation point below zero.	Incorrect linearisation point entered (must be between zero and full scale). Refer to Using Linearisation (K304 only) page 44 for more information.
(PT.TOO) (CLOSE)	An attempt has been made to place a calibration point too close to an existing calibration point.	Re-enter the calibration point. Points must be spaced by at least 2% of full scale from each other. Refer to Using Linearisation (K304 only) page 44 for more information.
(RES) (LO)	The scale build is configured for less than 100 graduations.	Check the resolution (count-by) and capacity settings.
(RES) (HIGH)	The scale build is configured for more than 30,000 graduations. (60,000 graduations for K307)	Check the resolution (count-by) and capacity settings.
(SPAN) (LO)	The load cell signal range (span) is too small for these settings.	Incorrect span weight entered (must be between zero and full scale). Scale wiring incorrect. Wrong load cell capacity (too large). Wrong or no calibration weight added to scale.
(SPAN) (HI)	The load cell signal range (span) is too large for these settings.	Incorrect span weight entered (must be between zero and full scale). Scale wiring incorrect. Load cell capacity too small for application.
(ZERO) (LO)	An attempt has been made to calibrate zero below -2mV/V.	Scale wiring incorrect
(ZERO) (HI)	An attempt has been made to calibrate zero above +2mV/V.	Remove all weight from scale. Scale wiring incorrect.

13.5. Diagnostic Errors

The instrument continually monitors the condition of the internal circuits. Any faults or out-of-tolerance conditions are shown on the display as an **E** type error message.

In the table below the following terms are used:

- **Check:** This item can be checked on site by service personnel.
- **Return for Service:** The instrument must be returned to the manufacturer for factory service.

Error	Description	Resolution
(E0001)	The power supply voltage is too low.	Check supply
(E0002)	The power supply voltage is too high.	Check scale / cables
(E0010)	The temperature is outside of allowable limits.	Check location
(E0020)	Scale build is incorrect. The number of graduations has been set too low or too high.	Fix up scale build
(E0100)	The digital setup information has been lost.	Re-enter setup
(E0200)	The calibration information has been lost.	Re-calibrate
(E0300)	All setup information has been lost	Enter setup and calibrate
(E0400)	The factory information has been lost.	Return for Service
(E0800)	The EEPROM memory storage chip has failed	Return for Service
(E2000)	ADC Out of Range Error. This may be caused from a broken load cell cable.	Check BUILD:CABLE setting. Check load cell cable, wiring, etc.
(E4000)	The battery backed RAM data has lost data.	Re-enter setup
(E8000)	The FLASH program memory is incorrect	Return for Service

The **E** type error messages are additive. For example if instrument is running off batteries and the temperature drops, the battery voltage may be too low. The resulting error messages will be **E 0011** (0001 + 0010). The numbers add in hexadecimal as follows:

1 - 2 - 3 - 4 - 5 - 6 - 7 - 8 - 9 - A - B - C - D - E - F
 (For example, 2 + 4 = 6, or 4 + 8 = C)

13.6. Glossary Terms

Term	Definition
COMM	The communications protocol used to communicate with the R300 Series
Count-by	The smallest change in weight units that the display can show. See also Resolution.
Division	A single graduation.
EEPROM	Electrically Erasable Programmable Read-Only Memory
EMC	Electro-Magnetic Compatibility Regulation
FIR	Finite Impulse Response
Full Scale	The maximum gross weight allowed on the scale. This is used to detect overload and underload conditions, etc.
Graduations	The maximum number of display steps between zero gross load and full capacity gross load. It is equal to the full scale divided by the resolution.
LED	Light Emitting Diode
NSC	National Standards Commission
NTEP	National Type Evaluation Program
OIML	International Organization of Legal Metrology
opto-LINK Cable	opto-isolated infrared communications link cable
PLC	Programmable Logic Controller
Range	Total change in weight between zero gross load and full capacity gross load (ie. the nominated total capacity of the scale). It is always given in displayed weight units.
Resolution	The smallest change in weight units that the display can show. See also Count-by.
RFI	Radio Frequency Interference
Ring Network	A network of up to 31 Instruments connected to a central computer
RS-232	Standard for communications hardware layers.
Step-Response	The step-response is the time between placing a weight on the scale and the correct weight reading being displayed.
Transients	A temporary voltage oscillation or spike caused by a sudden change of load (or other external influence).
Units	The actual units of measurement (kilograms, tonnes, pounds, etc.).

13.7. List of Figures

Figure 1: Weight Indicator	4
Figure 2: Cable Connections	8
Figure 3: 4-Wire Connections	9
Figure 4: 6-Wire Connections	9
Figure 5: RS-232 – One Instrument to PC using COM Port (DB9)	10
Figure 6: RS-232 – One Instrument to PC using COM Port (DB25)	10
Figure 7: RS-232 Short Cable Runs: Ring Network using COM Port (DB9)	11
Figure 8: RS-232 Long Cable Runs: Ring Network using COM Port (DB9)	12
Figure 9: RS-232 – Instrument to Printer (DB25)	13
Figure 10: Remote Input	13
Figure 11: Instrument Outputs to Drive Relay	14
Figure 12: Instrument Outputs to Drive PLC	15
Figure 13: opto-LINK Attachment	16
Figure 14: Editing Annunciators	18
Figure 15: Display and Controls Illustration	20
Figure 16: Chart - Zero and Span Points to Interpolate Weight from Load Cell	42
Figure 17: Chart - Non-Linear Characteristic for Load Cell Output	44

13.8. List of Tables

Table 1: Status Annunciators	21
Table 2: Industrial vs NSC, OIML and NTEP Modes	28

14. Index

- 4**
4-Wire Connection, 9
- 6**
6-Wire Connection, 9
- A**
A.TARE, 55
Accumulation, 49
ADDRES, 39
AUT.OFF, 37, 38
Automatic Weight Output, 47, 48
Auxiliary Connection, 10, 47, 52
- B**
B.LIGHT, 37, 60
Basic Operation, 20
Basic Weighing Terminology, 25
BAUD, 39, 60
BITS, 39, 60
BUILD, 33
- C**
CABLE, 8, 9, 33, 59
Cable Connections, 8
CAL, 35
Calibration, 42
Calibration Counter, 28
CAP, 33, 59
Check Weigh Operation, 52
Check Weighing, 52
CHECK.W, 40, 56
Clear Linearisation, 45
CLOCK, 40
CLR.LIN, 35, 45, 59
COMM Protocol, 47
Communications Manual, 5
Connecting Shields, 17
COUNT, 53
- D**
Data Entry, 18
 Numeric Entry, 19
 Selections and Options, 19
DAY, 40
DC Power Supply, 8
DEFLT, 40, 41
Diagnostic Errors, 63
Digital Calibration with Test Weights, 42
DIR.SPN, 35, 59
DIR.ZER, 35, 59
Direct mV/V Calibration, 43
Direct Span Calibration, 44
Direct Zero Calibration, 43
Document Conventions, 5
DP, 33, 59
- dual range, 21, 26, 27, 33
- E**
Earthing, 17
ED.LIN, 35, 45, 59
Edit Linearisation Points, 45
Editing Annunciators, 18, 22
Electrical Safety, 7
EMC Immunity, 7
End – Leaving Setup, 41
Error Messages, 61
Exiting Digital Setup, 41, 60
Exiting Full or Safe Setup, 31
External Output Drivers - Connection, 52
- F**
FAC.CAL, 35, 41, 59
FILTER, 34
FILTER (Reading Average), 59
Filtering Techniques, 28
FORMAT (Date), 40, 60
FRC.OUT, 40, 60
Front Panel, 20
 Special Function Key, 53
Full Digital Setup Passcode, 36
Full Setup Passcode, 29
FULL.PC, 36
FUNCTION Key, 24, 53
Function Keys, 21
 Editing Function, 22
 Primary Function, 21
- G**
General Setup Information, 25
Glossary of Terms, 64
GRADS, 33, 59
Gravity, 27, 35, 46
GROSS/NET Key, 24
 opto-LINK Activation, 24
Group and Items, 32
Groups and Items, 33
- H**
HI.RES, 33, 55, 59
HOLD, 54
HOUR, 40
- I**
Industrial vs OIML and NTEP Mode, 28
INIT.Z, 34, 59
- K**
Key Functions, 53
KEY.FN, 37, 53, 60
KEY.LOC, 37
Keypad Normal Operation, 18
- L**
L.in P, 35, 45
LIVE.WT, 54
Load Cell Connection, 8
Load Cell Signals, 8
- M**
Master Serial Output, 48, 50
MINUTE, 40
MONTH, 40
MOTION, 22, 34, 59
- N**
NONE, 53
NVRAM, 4
- O**
Operator Manual, 5
OPTION, 34
OPTION (Scale Options), 22
opto-LINK, 15
Outputs, 14
OVER, 40
- P**
Passcode, 25
PEAK HOLD, 54
POWER Key, 22
 Automatic Operation, 22
PRINT Key, 24
Printing
 Counting Information, 49
 Counting Sample, 49, 51
 Format, 49
 Gross or Net, 49
- Q**
Quick Start Manual, 5
- R**
Reference Manual, 5
REM.FN, 37
Remote Function, 13, 37
Remote Input, 13
RES, 33, 34, 59
Restore Factory Settings, 40, 41
RFI, 64
Ring Network Enhancement, 47
RS-232 Serial, 10
RST.CON, 39
- S**
S.in P, 35, 43
Safe Setup Passcode, 29
SAFE.PC, 36
- SCALE, 8, 60
SCALE (Scale Base Test Display), 40
Scale Build, 8, 35
Sealing Details, 58
Sealing Requirements, 17
SERIAL, 39, 48
Serial Communications, 48
Serial Output, 47
Serial PC Link, 10, 11
Serial Printer Connections, 11, 13
Serial Remote Display, 13
Setup Display Prompts, 31
Setup Errors, 62
Setup Menu Quick Reference, 59
SHOW.T, 55
Sigma-Delta A/D converter, 4
SPAN, 35, 59
Span Calibration Routine, 43
SPEC, 36
Special Functions, 53
Specifications, 5, 6
SRC, 40, 60
Stability Considerations, 22
- T**
TARE Key, 23
TEST, 53
TEST (Special Test Functions), 40
TYPE (Serial Output), 39
- U**
UNDER, 40
UNITS, 33, 53, 59
Units Display, 20
USE, 28, 29, 34, 59
Using Linearisation, 44, 62
- W**
W.D.LOCK, 38, 60
Weighing Errors, 61
Weight Display, 20
- Y**
YEAR, 40
- Z**
Z.BAND, 34, 59
Z.in P, 35, 43
Z.RANGE, 23, 34, 59
Z.TRAC, 34, 59
ZERO, 35, 59
Zero Calibration Routine, 43
ZERO Key, 23

Notes:

Notes:

Notes:

Notes:

SMART WEIGHING SOLUTIONS

