



Dynamic Axle Weighing Operator Sheets

ADD a Permanent Truck ID




- A long press (hold for 2sec) of the <UP> arrow (**Add**) to create a new **permanent** truck ID.
- The name of the new truck must be specified.
- If a truck exists with that name it will be selected, otherwise a temporary truck with that name will be created.

ADD a Temporary Truck ID




- If a name isn't specified a temporary one is allocated - format TNum (eg. T12).
- A short press of the Truck key to enter a name followed by the <OK> key.
- **A temporary Truck ID is automatically deleted at the end of the weigh out process.**

Select a Stored Truck ID



- A short press of <UP> and <DOWN> arrow keys to select a truck from the last ten (10) used.
- To select a stored truck – enter first letter/number of the stored truck name via the keypad.
- <UP> and <DOWN> keys to step through the list of trucks starting with the entered letter.

EDIT a Truck ID - Long Press of the OK Key (Edit)



- A long press (hold for 2sec) of the <DOWN> arrow (Del) Key to delete a truck.
- Trucks can only be deleted if the total weight is 0
- Truck totals can be cleared using a long press of the 4 key (Total)

DELETE a Truck ID - Long Press of the Down Key (Del)



Single Pass

Print Current Weight of Truck

AXLE 1 : 97881b
 AXLE 2 : 99991b
 AXLE 3 : 99931b
 AXLE 4 : 99801b
 AXLE 5 : 99601b
 19/09/13 15:03:05
 SEQ: 000000053

AXLES: 5
 TOTALS: 497201b

Automatic Temporary ID Allocated with a Preset Tare

TRUCK? → WEIGH IN 0 lb → 25000 lb

Temporary ID Allocated Automatically

Tare: 25,000lb →

Drive Truck Over Scale Completely

Total Displayed

10/02/10 09:50:00
 TRUCK: T12
 SEQ: 000000176

AXLES: 5
 GROSS: 497201b
 TARE: 250001b PT
 NET: 247201b

Single Pass

Permanent Truck ID with Preset Tare

TRUCK? → TRUCK? 111ABC →

ID: 111ABC
 Tare: 25,000lb →

Drive Truck Over Scale Completely

Total Displayed

10/02/10 09:50:00
 TRUCK: 111ABC
 SEQ: 000000176

AXLES: 5
 GROSS: 497201b
 TARE: 250001b PT
 NET: 247201b

Temporary ID (Operator Entered) with a Preset Tare

TRUCK? → TRUCK? 111ABC → WEIGH IN 111ABC

To change between types of string editing

ID: 111ABC
 Tare: 25,000lb →

Drive Truck Over Scale Completely

Total Displayed

10/02/10 09:50:00
 TRUCK: 111ABC
 SEQ: 000000176

AXLES: 5
 GROSS: 497201b
 TARE: 250001b PT
 NET: 247201b

Dynamic Axle Weighing Operator Sheets

Two Pass
Weigh In – Weigh Out

AXLE 1 :	6000
AXLE 2 :	5800
AXLE 3 :	6000
AXLE 4 :	5900
AXLE 5 :	6310
10/02/10-09:38:45	
TRUCK:	ABC123
SEQ:	000000173
AXLES:	5
WEIGH IN:	30010lb

AXLE 1 :	11200
AXLE 2 :	12300
AXLE 3 :	10100
AXLE 4 :	12900
AXLE 5 :	13179
10/02/10 09:38:45	
TRUCK:	ABC123
SEQ:	000000173
WEIGH IN:	30010lb
WEIGH OUT:	59679lb
NET:	29669lb

Two Pass
Automatic Temporary ID Allocated

AXLE 1 :	6000
AXLE 2 :	5800
AXLE 3 :	6000
AXLE 4 :	5900
AXLE 5 :	6332
10/02/10-09:38:45	
TRUCK:	T2
SEQ:	000000173
AXLES:	5
WEIGH IN:	30032 lb

AXLE 1 :	11200
AXLE 2 :	12300
AXLE 3 :	10100
AXLE 4 :	12900
AXLE 5 :	13615
10/02/10 09:38:45	
TRUCK:	T2
SEQ:	000000173
WEIGH IN:	30032lb
WEIGH OUT:	60115lb
NET:	30083lb